



INSTRUCTIONS FOR: ALUMINIUM RACING JACK MODEL: 1000RJ

Your new Jack is produced and manufactured to a high standard of dependability and will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS JACK CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. RETAIN THESE INSTRUCTIONS FOR FUTURE USE.

1. SAFETY PRECAUTIONS

- ✓ Ensure the jack is in sound condition and good working order. Take action for immediate repair or replacement of damaged parts.
Use genuine parts only. The use of improper parts may be dangerous and will invalidate the warranty.
- ✓ Locate the jack in a suitable, well lit working area.
- ✓ Keep working area clean and tidy and free from unrelated materials.
- ✓ Use jack on level and solid ground, preferably concrete. *Avoid tarmacadam as jack may sink in.*
- ✓ Place wedges under wheels of vehicle (*but ensure wheels of jack can freely move*).
- ✓ Ensure the vehicle handbrake is engaged, engine is switched off and transmission is in gear (or "PARK" if automatic).
- ✓ Ensure minimum distance of 0.5m between vehicle and static objects such as doors, walls, etc., to allow for vehicle tilting.
- ✓ Ensure all non-essential persons keep a safe distance whilst the jack is in use.
- ✓ Ensure there are no passengers in the vehicle.
- ✓ Place jack under only those lifting points recommended by vehicle manufacturer (*see vehicle hand book*).
- ✓ Check that the lifting point is stable and centred on the jack saddle.
- ✓ Ensure the jack wheels are free to move and that there are no obstructions.
- ☐ **DANGER:** *Use the jack for lifting only, NOT for supporting the lifted load.*
- ✓ Ensure there are no persons or obstructions beneath the vehicle before lowering.

- ✓ Use correct axle stands under the vehicle before proceeding with any task.
- ✓ Use a qualified person to lubricate and maintain the jack.
- ✓ Confirm that the recommended *hydraulic jack oil* is used during maintenance.
- ✗ DO NOT operate the jack if damaged.
- ✗ DO NOT allow untrained persons to operate the jack.
- ✗ DO NOT exceed the rated capacity of the jack.
- ✗ DO NOT allow the vehicle to move during jacking, or use the jack to move the vehicle.
- ✗ DO NOT jack vehicle if there is a risk of spillage of fuel, battery acid, or other dangerous substances.
- ✗ DO NOT work under the vehicle until axle stands have been correctly positioned.
- ✗ DO NOT use the jack for purposes other than which it is intended.
- ✗ DO NOT top up hydraulic system with brake fluid. Use hydraulic jack oil only.
- ✗ DO NOT adjust the safety overload valve.
- ✓ When not in use store jack, fully lowered, in a safe, dry, childproof area.

Model 1000RJ Specifications

Capacity	1000kg
Min. saddle height	95mm
Max. saddle height	446mm
Hydraulic lift	351mm
Length/Width/Height	600/290/155mm
Weight	17kg

2. ASSEMBLY

- 2.1. Line up the holes in the two piece handle and fasten with the assembly screw.
- 2.2. Loosen location bolt at the side of the handle base. Insert jack handle and screw in the bolt to engage with groove in end of handle. Check that rotating the handle rotates the release valve shaft.

3. OPERATING INSTRUCTIONS

3.1. Before first use.

Note that the jack has side handles to assist in positioning and carrying the unit.

- 3.1.1. Before using the jack, purge hydraulic circuit in order to eliminate any air in the system by turning the handle anti-clockwise to open release valve, and pumping 3 or 4 times (fig.1).
- 3.1.2. Place a few drops of hydraulic jack oil on the pump piston and pump the handle several times to distribute the oil. Thoroughly lubricate all moving parts.

3.2. General jacking.

☐ **WARNING!** *Before lifting ensure Section 1 safety instructions are strictly followed.*

- 3.2.1. Prepare the vehicle as mentioned in the safety instructions ensuring the ground on which the jack is to stand is level and solid (not tarmacadam).
- 3.2.2. Position the jack saddle under the vehicle manufacturer's recommended lifting point.


3.3. Jacking the vehicle.

- 3.3.1. Turn the handle clockwise to close the release valve and commence pumping the handle up and down using maximum strokes until the vehicle reaches the working height.
- 3.3.2. Should the jack become overloaded, a safety excess pressure valve will open, and stop the vehicle from lifting.

3.4. Lowering the vehicle

- 3.4.1. Turn the handle anti-clockwise, very slowly, to open the valve.
- 3.4.2. The lowering speed is controlled by the amount you turn the handle. Lower carefully, avoid any sudden changes in descent rate which would shock load the hydraulic system.

☐ **WARNING!** *Ensure there are no persons or obstacles beneath the vehicle, or in the path of its descent.*



4. MAINTENANCE

IMPORTANT: Only fully qualified personnel should attempt maintenance or repair.


- 4.1. When the jack is not in use, the ram should be in its lowest position to minimise corrosion. Remove the handle to inactivate jack.
- 4.2. Keep the jack clean and lubricate all moving parts with acid free oil on a regular basis.
- 4.3. To check the oil level, fully lower the jack. Remove knurled filler screw (fig.2). The correct level is the bottom of the screw hole. If oil level is low, fill as required.

NOTE: Use a good quality jack oil, such as SEALEY HYDRAULIC JACK OIL.

WARNING: DO NOT use brake fluid, or any fluid other than hydraulic jack fluid as this may cause serious damage to the jack and will invalidate the warranty!

- 4.4. Before each use check for broken, cracked, bent, or loose parts, or any visible damage to ram, pump, saddle, lifting arm, frame and all parts including nuts, bolts, pins and other fasteners. If any suspect item is found remove jack from service and take necessary action to remedy the problem. DO NOT use the jack if believed to have been subjected to abnormal load or shock. Inspect and take appropriate action.
- 4.5. After one year the oil should be replaced in order to extend the life of the equipment. To drain the oil, remove the filler plug and raise front of jack. Make sure that no dirt is allowed to enter the hydraulic system. See 4.3. for refill instructions.
- 4.6. Periodically check the pump piston and the ram for signs of corrosion. Clean exposed areas with a clean oiled cloth.

fig. 2



IMPORTANT: NO RESPONSIBILITY IS ACCEPTED FOR INCORRECT USE OF THIS PRODUCT.

Hydraulic products are only repaired by local service agents. We have service/repair agents in all parts of the UK.

DO NOT RETURN JACKS TO US. Please telephone us on 01284 757500 to obtain the address and 'phone number of your local agent. If jack is under guarantee you can also contact your local dealer.

De-commissioning the Jack

Should the jack become completely unserviceable and require disposal, draw off the oil into an approved container and dispose of the jack and the oil according to local regulations.

5. TROUBLE SHOOTING

PROBLEM	POSSIBLE CAUSE	REMEDY
Jack will not lift the load	<ol style="list-style-type: none"> 1) Overloaded 2) Oil level low 3) Release valve not correctly closed 4) Air in system 5) Piston rod not functioning 6) Packing worn or defective 	<ol style="list-style-type: none"> 1) Be sure to use jack with adequate capacity 2) Top up oil level 3) Check and close release valve 4) Open release valve and pump the handle a few times. Close valve and re-try 5) Clean and replace oil 6) Replace packing
Jack does not lift high enough or feels "spongy"	<ol style="list-style-type: none"> 1) Oil level too high or too low 2) Worn seals 3) Air in system 4) Release valve not closed 	<ol style="list-style-type: none"> 1) Fill or remove excess oil 2) Return jack to local service agent 3) Open release valve and pump the handle a few times. Close valve and re-try 4) Check and close release valve
Jack lifts poorly	<ol style="list-style-type: none"> 1) Pump packing or valves malfunctioning 2) Oil is dirty 3) Air in the system 	<ol style="list-style-type: none"> 1) Replace packing and/or clean valves 2) Replace oil 3) Open release valve and pump the handle a few times. Close valve and re-try
Jack lifts but will not hold load	<ol style="list-style-type: none"> 1) Release valve partially open 2) Dirt on valve seats 3) Air in system 4) Faulty seals 5) Packing worn or defective 	<ol style="list-style-type: none"> 1) Check and close release valve 2) Lower jack, close release valve. Place foot on front wheel and pull up lifting arm to it's full height by hand. Open the release valve to lower arm 3) Open release valve and pump the handle a few times. Close valve and re-try 4) Replace packing or contact local service agent 5) Replace packing
Jack will not lower completely	<ol style="list-style-type: none"> 1) Unit requires lubrication 2) Piston rod bent or damaged 3) Jack frame/link system distorted due to overloading/poor positioning 4) Air in system 5) Release valve partially closed 6) Jack spring damaged 	<ol style="list-style-type: none"> 1) Oil all external moving parts 2) Replace rod or contact local service agent 3) Replace damaged parts or contact local service agent 4) Open release valve and pump the handle a few times. Close valve and re-try 5) Check and fully open release valve 6) Replace spring or contact local service agent
Jack does not lower at all	<ol style="list-style-type: none"> 1) Release valve closed 	<ol style="list-style-type: none"> 1) Check and fully open release valve

Declaration of Conformity

We, the sole importer into the UK, declare that the product listed below is in conformity with the following EEC standards and directives

ALUMINIUM RACING JACK
Model: 1000RJ

93/68/EEC CE Marking Directive
98/37/EEC Machinery Directive (S.I.1992/3073 & Amendments)



The construction file for this product is held by the Manufacturer and may be inspected on request by contacting Jack Sealey Ltd.

Signed by Mark Sweetman

2nd August 1999

For Jack Sealey Ltd. Sole importer into the UK of Sealey Quality Machinery.



Sole U.K. Distributor
Sealey Group,
Bury St. Edmunds, Suffolk.



01284 757500



01284 703534

E-mail: sales@sealey.co.uk