

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



**IMPORTANT: READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS JACK CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. RETAIN THESE INSTRUCTIONS FOR FUTURE USE.**

## 1. SAFETY PRECAUTIONS

- ✓ Ensure the jack is in sound condition and good working order. Take action for immediate repair or replacement of damaged parts.  
*Use genuine parts only. The use of unauthorised parts may be dangerous and will invalidate the warranty.*
- ✓ Locate the jack in a suitable, well lit working area.
- ✓ Keep working area clean and tidy and free from unrelated materials.
- ✓ Use jack on level and solid ground, preferably concrete. *Avoid tarmac as jack may sink in.*
- ✓ Place wedges under wheels of vehicle (*but ensure wheels of jack can move freely*).
- ✓ Ensure the vehicle handbrake is engaged, engine is switched off and transmission is in 1st or reverse gear (or "PARK" if automatic).
- ✓ Ensure minimum distance of 0.5m between vehicle and static objects such as doors, walls, etc., to allow for vehicle tilting.
- ✓ Ensure there are no passengers in the vehicle.
- ✓ Ensure all non-essential persons keep a safe distance whilst the jack is in use.
- ✓ Only place jack under those lifting points recommended by vehicle manufacturer (*see vehicle hand book*).
- ✓ Check the lifting point is stable and centred on the jack saddle.
- ✓ Ensure the jack wheels are free to move and that there are no obstructions.
- ☐ **DANGER:** Use the jack for lifting only, NOT for supporting the lifted load.
- ✓ Once the vehicle is raised use suitable capacity axle stands before proceeding with any task.
- ✓ Ensure there are no persons or obstructions beneath the vehicle before lowering.
- ✓ Use a qualified person to maintain or repair the jack hydraulic system.
- ✗ **DO NOT** operate the jack if damaged.
- ✗ **DO NOT** allow untrained persons to operate the jack.
- ✗ **DO NOT** exceed the rated capacity of the jack.
- ✗ **DO NOT** allow the vehicle to move while supported by the jack, nor use the jack to move the vehicle.
- ✗ **DO NOT** jack vehicle if there is a risk of spillage of fuel, battery acid, or other dangerous substance.
- ✗ **DO NOT** work under the vehicle until axle stands have been correctly positioned.
- ✗ **DO NOT** use the jack for purposes other than that for which it is designed.
- ✗ **DO NOT** top up hydraulic system with brake fluid. Use hydraulic jack oil only.
- ✗ **DO NOT** adjust the safety overload valve.
- ✓ When not in use store jack, fully lowered, in a safe, dry, childproof area.

## 2. SPECIFICATION


Capacity .....	1.5 ton
Min. Saddle Height .....	100mm
Max. Saddle Height .....	820mm
Max. Chassis Height.....	170mm
Length.....	980mm
Weight.....	64kg

## 3. ASSEMBLY & PURGING

**Note: Numbers in brackets refer to item numbers in the Parts List.**

- 3.1. Insert the waisted portion of the upper handle assembly (12-2-A) into the lower handle assembly tube (12-1-A). Align the holes in the tubes and fix together using the bolt provided (12-3).

- 3.2. Loosen location bolt (12-10) at the front of the handle fork socket (11-3). Place the handle into the socket and press it home. Retighten the location bolt, ensuring that it fits correctly in the slot. Check that the handle can be raised and then turned anticlockwise.
- 3.3. Before using the jack for the first time, purge the hydraulic circuit in order to eliminate any air in the system. To do so pull the handle upward and turn it anticlockwise to open the release valve. Hold the handle in the open position and pump it up and down 15 to 20 times. (see fig.1A) At the end of the last downward stroke shut the valve off again by turning the handle clockwise.
- 3.4. Place a few drops of hydraulic jack oil on the pump piston and pump the handle several times to distribute the oil. Thoroughly lubricate all moving parts.



## 4. OPERATING INSTRUCTIONS

- 4.1. **General jacking.** ☐ **WARNING!** Before lifting, ensure **Section 1 safety instructions are strictly followed.**
- 4.2. Prepare vehicle as described in safety instructions ensuring the ground on which jack is to stand is level and solid (not tarmac).
- 4.3. Position the jack saddle under the vehicle manufacturer's recommended lifting point (see vehicle handbook).
- 4.4. **Jacking the vehicle.** Ensure the release valve is closed (i.e. the handle is turned fully clockwise and pushed down). Commence pumping the handle up and down using maximum strokes until the vehicle reaches the working height.
- 4.5. Should the jack become overloaded, the safety valve will open, and stop the jack from lifting.
- 4.6. **Lowering the vehicle.** Pull the handle up and turn it anticlockwise to open the valve and lower the load.
- 4.7. The lowering speed is controlled by the amount you turn the handle. Lower slowly and carefully, avoiding sudden release.  
 ☐ **WARNING!** Ensure there are no persons or obstacles beneath the vehicle, or in the path of its descent.

## 5. MAINTENANCE

**IMPORTANT:** Only fully qualified personnel should attempt maintenance or repair.

- 5.1. When the Jack is not in use, the ram and the handle socket should be in their lowest position to minimise corrosion. Remove the handle to inactivate Jack.
- 5.2. Keep the Jack clean and lubricate all moving parts on a regular basis.
- 5.3. To check the oil level, fully lower the Jack. Remove filler plug (fig.1B). The correct oil level should be approximately 5mm below the filler opening. If oil level is low, fill as required. Pump unloaded jack 15 to 20 times to expel air and then refit plug.  
**NOTE:** Use a good quality jack oil, such as SEALEY HYDRAULIC JACK OIL. Part numbers, 5ltr **HJO5LS**, 500ml **HJO500MLS**.

- WARNING: DO NOT use brake fluid, or any fluid other than hydraulic jack fluid as this may cause serious damage to the Jack and will invalidate the warranty!**
- 5.4. Before each use check for broken, cracked, bent, or loose parts, or any visible damage to welds, ram, pump, saddle, lifting arm, frame and all parts including nuts, bolts, pins and other fasteners. If any suspect item is found remove jack from service and take necessary action to remedy the problem. DO NOT use the jack if believed to have been subjected to abnormal load or shock. Inspect and take appropriate action.
- 5.5. Every three months remove the locking rings on the caster wheels and lubricate the ball bearings with grease.
- 5.6. After a year of extensive use, the oil should be replaced in order to extend the life of your jack. To drain the oil, remove the filler cap and valve. Make sure that no dirt is allowed to enter the hydraulic system's oil. Dispose of oil according to local authority regulations. See 5.3. for refill instructions.
- 5.7. Periodically check the pump piston and piston rod for signs of corrosion. Clean exposed areas with a clean oiled cloth.

**IMPORTANT: NO RESPONSIBILITY IS ACCEPTED FOR INCORRECT USE OF THE JACK.**

Hydraulic products are only repaired by local service agents. We have service/repair agents in all parts of the UK.

**DO NOT RETURN JACKS TO US.** Please telephone us on 01284 757500 to obtain the address and phone number of your local agent.

If Jack is under guarantee please contact your dealer.

**De-commissioning the Jack**

Should the Jack become completely unserviceable and require disposal, draw off the oil into an approved container and dispose of the Jack and the oil according to local regulations.

**6. TROUBLESHOOTING**

PROBLEM	POSSIBLE CAUSE	REMEDY
Jack will not lift the load	1) Overloaded	1) Be sure to use a jack with adequate lifting capacity
	2) Oil level low	2) Top up oil level
	3) Release valve not correctly closed	3) Check and close release valve
	4) Air in system	4) Open release valve and air vent (if fitted) and pump the handle 15 to 20 times. Close valve and re-try
	5) Piston rod not functioning	5) Clean and replace oil
	6) Packing worn or defective	6) Replace packing
Jack does not lift high enough or feels "spongy"	1) Oil level too high or too low	1) Fill or remove excess oil
	2) Worn seals	2) Return jack to local service agent
	3) Air in system	3) Open release valve and air vent (if fitted) and pump the handle 15 to 20 times. Close valve and re-try
	4) Release valve not closed	4) Check and close release valve
Jack lifts poorly	1) Pump packing or valves malfunctioning	1) Replace packing and/or clean valves
	2) Oil is dirty	2) Replace oil
	3) Air in the system	3) Open release valve and air vent (if fitted) and pump the handle 15 to 20 times. Close valve and re-try
Jack lifts but will not hold load	1) Release valve partially open	1) Check and close release valve
	2) Dirt on valve seats	2) Lower jack, close release valve. Place foot on front wheel and pull up lifting arm to it's full height by hand. Open the release valve to lower arm
	3) Air in system	3) Open release valve and air vent (if fitted) and pump the handle 15 to 20 times. Close valve and re-try
	4) Faulty seals	4) Replace packing or contact local service agent
	5) Packing worn or defective	5) Replace packing
Jack will not lower completely	1) Unit requires lubrication	1) Oil all external moving parts
	2) Piston rod bent or damaged	2) Replace rod or contact local service agent
	3) Jack frame/link system distorted due to overloading/poor positioning	3) Replace damaged parts or contact local service agent
	4) Air in system	4) Open release valve and air vent (if fitted) and pump the handle 15 to 20 times. Close valve and re-try
	5) Release valve partially open	5) Check and fully open release valve
	6) Jack spring damaged	6) Replace spring or contact local service agent
Jack does not lower at all	1) Release valve still closed	1) Check and fully open release valve

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**IMPORTANT:** No liability is accepted for incorrect use of this product.

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.

**INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



**Sole UK Distributor, Sealey Group,**  
Kempson Way, Suffolk Business Park,  
Bury St. Edmunds, Suffolk,  
IP32 7AR

01284 757500

[www.sealey.co.uk](http://www.sealey.co.uk)

01284 703534

[sales@sealey.co.uk](mailto:sales@sealey.co.uk)