

SEALEY

10.8V SV10.8 SERIES CORDLESS GRASS TRIMMER

MODEL NO: CP108VGSBO

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instruction manual



Wear protective gloves



Wear face shield



Wear ear protection



Wear protective clothing



Do not use in rain



Wear appropriate footwear



DANGER
be aware of thrown objects



Keep bystanders Away

1. SAFETY

1.1. GENERAL POWER TOOL SAFETY WARNINGS

Read all the safety warnings, instructions, illustrations, and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

- ✓ Save all warning and instructions for future reference.
 - ✓ Only to be used by those familiar with these instructions.
 - ✓ Inspect and ensure equipment is in good working order before use.
 - ❑ **WARNING!** Keep all parts of the body away from the cutter blade. **DO NOT** remove cut material or hold material to be cut when blades are moving. Make sure the switch is **OFF** when clearing jammed material. A moment of inattention while operating the tool may result in serious personal injury.
 - ❑ **WARNING!** Carry by the handle with the cutter blade stopped. Proper handling of the tool will reduce possible personal injury from the cutter blades.
 - ❑ **WARNING!** Risk assess the work area. Keep bystanders and children away from the work area. **DO NOT** operate with anyone or pets nearby. Check intended work area for wildlife and for foreign objects, electrical cables etc.
 - * Never replace the non-metallic cutting means with metallic cutting means.
 - ✓ Remove the battery when the following occurs:
 - The machine is left by the user
 - Before clearing a blockage
 - Before checking, cleaning or working on the machine
 - After striking a foreign object to inspect the machine for damage
 - If the machine starts to vibrate abnormally.
 - * Never operate the machine with a defective guard or shield, or without safety devices.
 - ✓ Avoid using the machine in bad weather conditions, especially when there is a risk of lightning
 - ❑ **WARNING!** Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of a power tool may result in personal injury.
 - ✓ Prevent unintentional starting. Ensure the switch is in the off position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your fingers on the switch or energising power tools that have the switch on invites accidents.
 - ❑ **WARNING! DO NOT** allow water to enter into power tool. This will increase the risk of an electric shock.
 - ❑ **WARNING!** Never allow children, persons with reduced physical sensory or mental capabilities or lack of experience and knowledge or people unfamiliar with these instructions to use the machine, local regulations may restrict the age of the operator.
 - ❑ **WARNING!** Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.
 - ❑ **WARNING!** Use of the power tool, accessories, and tool bits etc, in accordance with these instructions, taking into account the working conditions, and the work to be performed. **DO NOT** use for a task it was not designed to perform.
- 1.1.1. **WHAT TO DO IN CASE OF ACCIDENT OR BREAKDOWN:**
- * **DO NOT** use if tool is accidentally knocked. Test for normal operation first. If tool vibrates abnormally, switch off, remove battery and then inspect. Contact Sealey for help.
 - * **DO NOT** touch hazardous moving parts. Allow tool to come to a complete stop first.
 - * **DO NOT** use if damaged. **DO NOT** operate with defective guards or shields or without safety devices, and protective clothing.
 - ✓ Always store with the battery removed and separate from the power tool, in a dry, childproof location.
 - * **DO NOT** force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- 1.2. **WORK AREA SAFETY**
- * **DO NOT** operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power tools create sparks which may ignite the dust or fumes.
- 1.3. **ELECTRICAL/BATTERY SAFETY**
- * **DO NOT** expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
 - ✓ Ensure batteries are inserted with the correct polarity.
 - ✓ The supply terminals must not be short circuited.
- 1.4. **MAINTENANCE**
- ❑ **WARNING!** Remove battery before attempting any cleaning, maintaining or storing the device.

- ✓ There are no parts inside the equipment which require additional maintenance.
- ✓ Check for unexpected vibration or noises before each use.
- ✓ Check for misalignment or binding of the moving parts, breakage of parts and any other condition that may affect the power tool's operation.
- ✓ If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- ✓ Have your power tools serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.
- ✓ Never disassemble tool yourself. For servicing and repair always contact your local Sealey Service Centre, or place of purchase.

1.5. PERSONAL SAFETY

- ✓ Stay alert, watch what you are doing and use common sense when operating a power tool.
 - ✓ Always be sure of your footing on slopes and when walking with the machine. Never run.
 - ✗ **DO NOT** use a power tool whilst you are tired or under the influence of drugs, alcohol, or medication. A moment of inattention whilst operating power tools may result in serious injury.
 - ✓ Use personal protective equipment. Always wear eye protection. Protective equipment such as non-skid safety shoes, hard hat or hearing protection use for appropriate conditions will reduce personal injuries. Dress properly. **DO NOT** wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
 - ✓ Always wear substantial footwear and long trousers while operating the machine.
 - ✗ **DO NOT** over reach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- CAUTION:** Before installing the battery cartridge into the hedge trimmer, always check to see that the switch trigger and lock-off lever actuates properly and returns to the "OFF" position when released. **NOTE: DO NOT** pull the switch trigger hard without pressing the lock-off lever. This can cause switch breakage.
- ✓ Always use by firmly holding both handles during operation.

1.6. POWER TOOL USE AND CARE

- ✗ **DO NOT** force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- ✗ **DO NOT** use the power tool if the switch does not turn it **ON** and **OFF**. Any power tool that cannot be controlled with the switch is dangerous and must be repaired. Contact place of purchase, or Sealey Service centre.
- ✓ Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- ✓ Remove the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- ✓ Store idle power tools out of the reach of children and do not allow persons unfamiliar with these power tools or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
- ✓ Use the power tool, accessories, and tool bits etc, in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.
- ✓ Keep all parts of the body away from the cutter blade. **DO NOT** remove cut material or hold material to be cut when blades are moving.
- ✓ Make sure the switch is off when clearing jammed material. A moment of inattention while operating the hedge trimmer may result in serious personal injury.

2. INTRODUCTION


Lightweight, cordless grass trimmer makes gardening easy. Adjustable operation handle and auxiliary handle make for comfort in use. Supplied with pack of 10 replacement plastic blades.

3. SPECIFICATION


Model No:CP108VGSBO
 Battery: 10.8V 2Ah - 4Ah Lithium-ion (not included)
 Charger:.....CP108VMC (not included)
 Consumable Parts:
 CP108VBP - 2Ah Battery, CP108VBP4 - 4Ah Battery
 Cutting Mechanism:Plastic Blades
 Cutting Width:240mm
 Dimensions (W x D x H):..... 1160 x 260 x 340mm
 Weight:..... 1.10kg
 Replacement Parts: .. CS20VB - Replacement cutting blades
 Noise Power/Pressure: 88/76dB(A)
 Vibration/Uncertainty:..... 1.041/1.5m/s²
 Voltage:..... 10.8V Lithium-ion

4. FEATURES & ASSEMBLY


Slide (1) forwards then pull trigger (2) upwards to start. Release to stop




Fit battery: push in until a click is heard. Release by holding side buttons in



Adjust handle forwards or backwards




Loosen nut, adjust, tighten




9
10

Adjust length




2



Press button on side of handle
To adjust angle

1

Fit blades (6): Lower over spigot (1) pull outwards (2) to secure




6 4

3

5

Fit cover, secure with screw (5)



5. OPERATION

- 5.1. Read and follow Safety Instructions in Section 1. Only to be used by those already familiar with its use.
- 5.2. This tool is designed to cut grass and weeds in gardens along flower beds and borders. **DO NOT** use in any other way. **DO NOT** use to cut hedges, hard branches and wood or to crush material for compost. **DO NOT** use to cut grass that is not on the ground: grass growing on walls, on rocks etc.
- × **DO NOT** use metal wire or plastic sheathed wire of any kind in the cutting head. This may lead to serious injuries for the operator.
 - WARNING!** Remove battery before making any adjustments.
 - ✓ Ensure body is a safe distance from the blades before turning on.
 - WARNING!** Keep children and other persons including animals at least 15m away from the work area.
 - WARNING!** Only use this machine for its intended use.
 - WARNING!** The blade will continue to spin for a few seconds after the ON/OFF switch is released.
- 5.3. Inspect before each for any broken parts or misalignment.
- × **DO NOT** use: in poor light, in bad weather especially when there is risk of a storm, if you are tired, ill, or under the influence of drugs or alcohol or medication.
 - ✓ Walk **DO NOT** run. Be careful going backwards.
 - ✓ Be aware that stones or objects may be thrown.
 - × Never touch the motor housing whilst in use.
 - × **DO NOT** use the grass trimmer without the guard.
 - × **DO NOT** fit metal blades.
 - × **DO NOT** cut grass when it is wet. The best results are achieved with dry grass.
- 5.4. Always wear appropriate eye protection, ear protection, substantial footwear, gloves, long trousers whilst operating.
- 5.5. Always hold the tool using both handles.
- 5.6. **ADJUST HANDLES**
- 5.6.1. Always adjust handles before use to achieve proper posture and balance for use of tool.
- 5.6.2. REAR HANDLE: Push button on side of handle to adjust angle.
- 5.6.3. LOWER HANDLE: Angle can be adjusted by loosening nut.
- 5.7. Push the battery pack into the mount provided.
- 5.8. SWITCH ON: Slide top lever (1) forwards then pull trigger (2) upwards to start.
Release to stop.
- × **DO NOT** allow the grass trimmer near the grass until the switch is pressed and the grass trimmer is in operation.
- 5.9. To cut properly, swing the machine sideways while moving forwards. Keep the grass trimmer inclined at an angle of approx. 30° while you doing so.
- 5.10. If the grass is long, the grass must be cut shorter in stages.
- 5.11. To avoid unnecessary wear, keep the grass trimmer away from hard objects.
- 5.12. **FAULT IDENTIFICATION**
- 5.12.1. If tool does not work, check that battery is fully inserted and fully charged.
- 5.12.2. If this is unsuccessful contact Sealey service for assistance.

6. MAINTENANCE

- WARNING!** Remove battery pack before performing any Maintenance tasks.
- 6.1. **CLEANING**
- 6.1.1. Keep all safety devices, air vents and the motor housing free of dirt and dust as far as possible. Wipe the equipment with a clean cloth and mild soap, or blow it down with compressed air at low pressure.
- 6.1.2. Always clean the equipment immediately after use.
- 6.1.3. Clean the equipment with a damp cloth and some mild soap. **DO NOT** use cleaning agents or solvents, these may be aggressive to the plastic parts in the equipment. Ensure that no water can get into the interior of the equipment. The ingress of water into an electric tool increases the risk of an electric shock.
- 6.1.4. Use a brush to remove deposits from the safety guard.
- 6.2. **REPLACING THE BLADES**
- WARNING!** Be sure to remove the battery pack before replacing.
- 6.2.1. To remove the blade, push the blade inwards and remove it through the larger opening on the end of the blade.
- 6.2.2. To fit the new blade, proceed in reverse order. Make sure the blade locks into place correctly.
- 6.3. **STORAGE**
- 6.3.1. If tool is to be stored for a long period, remove battery. Store carefully in its original packaging (to protect it from damage) in a secure, dry place, out of the reach of children.

7. TRANSPORT

- 7.1. Tool must be protected from damage during transit.
- × **DO NOT** transport with battery inserted.

8. END OF LIFE

- 8.1. Remove battery.
- 8.2. Dismantle tool by reversing Assembly section above.
- 8.3. Dispose of according to local regulations in force.

- ❑ **WARNING!** – Risk of Hand Arm Vibration Injury.

This tool may cause Hand Arm Vibration Syndrome if its use is not managed adequately.

This tool is subject to the vibration testing section of the Machinery Directive 2006/42/EC.
This tool is to be operated in accordance with these instructions.

Measured vibration emission value (a): 1.041 m/s²

Uncertainty value (k): 1.5 m/s²

Please note that the application of the tool to a sole specialist task may produce a different average vibration emission. We recommend that a specific evaluation of the vibration emission is conducted prior to commencing with a specialist task.

A health and safety assessment by the user (or employer) will need to be carried out to determine the suitable duration of use for each tool.

NB: Stated Vibration Emission values are type-test values and are intended to be typical.

Whilst in use, the actual value will vary considerably from and depend on many factors.

Such factors include; the operator, the task and the inserted tool or consumable.

NB: ensure that the length of leader hoses is sufficient to allow unrestricted use, as this also helps to reduce vibration.

The state of maintenance of the tool itself is also an important factor, a poorly maintained tool will also increase the risk of Hand Arm Vibration Syndrome.

Health surveillance.

We recommend a programme of health surveillance to detect early symptoms of vibration injury so that management procedures can be modified accordingly.

Personal protective equipment.

We are not aware of any personal protective equipment (PPE) that provides protection against vibration injury that may result from the uncontrolled use of this tool. We recommend a sufficient supply of clothing (including gloves) to enable the operator to remain warm and dry and maintain good blood circulation in fingers etc. Please note that the most effective protection is prevention, please refer to the Correct Use and Maintenance section in these instructions. Guidance relating to the management of hand arm vibration can be found on the HSC website

www.hse.gov.uk - Hand-Arm Vibration at Work.



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way.

Contact your local solid waste authority for recycling information.



REGISTER YOUR PURCHASE HERE



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



sales@sealey.co.uk



www.sealey.co.uk