



PLATFORM TRUCK WITH FOLDING/ REMOVABLE SIDES

MODEL NO: **CST997.V2**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions

1. SAFETY

- ✓ Always distribute the load evenly over the surface of the bed.
- * **DO NOT** overload the truck. See specification.
- * **DO NOT** leave unattended, especially when loaded, unless the wheels are chocked or the truck is otherwise secured.
- * **DO NOT** use the truck on uneven ground.
- * **DO NOT** run over curbs or steps. Use a ramp.
- * **DO NOT** allow others to ride on the truck.
- * **DO NOT** use the truck if any part is damaged. Pay particular attention to the wheels.
- * **DO NOT** over inflate the tyres. See specification.

2. INTRODUCTION

Heavy-duty steel with hinged mesh construction. Cushioned grip pull handle with smooth steering action for easy manoeuvrability. Steel centred pneumatic wheels allow transport over the toughest terrain. Drop-down sides, for easy loading, are also removable, allowing use as a flatbed for oversized items. Suitable for a variety of warehouse, office, garden and domestic hauling applications.

3. SPECIFICATION

Model No:CST997.V2
 Capacity: 200kg
 Cart size, internal:220 x 480 x 930mm
 Overall height: 570mm
 Platform height: 350mm
 Wheel size:Ø259 x 90mm



4. ASSEMBLY

Unpack the product and check contents. Should there be any damaged or missing parts contact your supplier immediately.

Refer to attached parts list.

4.1. ATTACH REAR SUPPORT ASSEMBLY

- 4.1.1. Place the truck bed (fig 1 - 1) upside down onto a protected floor (use original packaging).
- 4.1.2. Position rear axle support (fig 1 - 6) onto the truck bed and secure with washer 8mm (fig 1 - 16), nut w/lock insert 8mm (fig 1 - 17) and M8 x 20 carriage support bolt (fig 1 - 21), finger tight only.
- 4.1.3. Position left rear axle support (fig 1 - 7) and secure with washer 8mm (fig 1 - 16), nut w/lock insert 8mm (fig 1 - 17) and M8 x 20 carriage support bolt (fig 1 - 21), finger tight only.
- 4.1.4. Position right rear axle support (fig 1 - 8) and secure with washer 8mm (fig 1 - 16), nut w/lock insert 8mm (fig 1 - 17) and M8 x 20 carriage support bolt (fig 1 - 21), finger tight only.
- 4.1.5. Fully tighten bolts.



4.2. ATTACH FRONT AXLE BRACE

- 4.2.1. Position front axle brace (fig 2 - 10) onto the truck bed and secure with washer 8mm (fig 2 - 16), nut w/lock insert 8mm (fig 2 - 17) and M8 x 20 carriage support bolt (fig 2 - 21), finger tight only.

4.3. ATTACH CENTRE AXLE BRACE

4.3.1. Position centre axle brace (fig 3 - 12) onto the truck bed and secure with washer 8mm (fig 3 - 16), nut w/lock insert 8mm (fig 3 - 17) and M8 x 20 carriage support bolt (fig 3 - 21), finger tight only.

4.4. ATTACH FRONT WHEEL SUPPORT BRACE

4.4.1. Locate the front wheel support brace (fig 4 - 13) on underside of wheel axle plates on front axle brace (fig 4 - 10) and secure with washer 8mm (fig 4 - 16), nut w/lock insert 8mm (fig 4 - 17) and M8 x 20 carriage support bolt (fig 4 - 21).

× **DO NOT** over tighten.

4.5. ATTACH FRONT AXLE SUPPORT

4.5.1. Locate fixing hole on lower arm of front axle support (fig 5 - 9) onto central fixed bolt on front axle brace (fig 5 - 10) and secure with pin (split) (fig 5 - 18).

4.5.2. Secure front axle support (fig 4 - 9) to front wheel support brace (fig 4 - 13) with washer 8mm (fig 4 - 16), nut w/lock insert 8mm (fig 4 - 17) and M8 x 20 carriage support bolt (fig 4 - 21).




× **DO NOT** over tighten.

4.5.3. Align the central hole on the upper arm of front axle support (fig 4 - 9), front wheel support brace (fig 4 - 13) and front axle brace and secure with washer 8mm (fig 4 - 16), nut w/lock insert 8mm (fig 4 - 17) and M8 x 25 carriage support bolt (fig 4 - 22).

× **DO NOT** over tighten.

4.5.4. Fully tighten bolts attaching front axle brace (fig 2 - 10) and centre axle brace (fig 3 - 12) to the truck bed ONLY.

NOTE: The front wheel support assembly should be free to move.



4.6. ATTACH THE WHEELS

4.6.1. Place a wheel (fig 7 - 5) onto each of the axles with the valve stem facing outwards.

4.6.2. Secure with wheel nut (fig 7 - 19) and wheel washer (fig 7 - 20).

× **DO NOT** over tighten. Allow the wheels to spin freely.

4.7. ATTACHING THE PULL HANDLE

4.7.1. With the assistance of another person turn the cart upright onto it's wheels.

4.7.2. Attach the pull handle (fig 7 - 11) and plastic coupling to the front axle support (fig 7 - 9) securing with pull handle bolt 8 x 60mm (fig 7 - 23), washer 8mm (fig 7 - 16) and nut w/lock insert 8mm (fig 7 - 17).

4.8. ATTACHING THE SIDE FENCES

4.8.1. Position side fence (fig 7 - 2) along side edge of bed (fig 7 - 1) and secure with fence assembly pin (fig 6 - 14) by inserting through hinge tubes.

4.8.2. Repeat for other side.

NOTE: The assistance of another person may be required for this operation.

4.9. ATTACHING THE FRONT FENCE

4.9.1. Position front fence (fig 7 - 3) along front edge of bed (fig 7 - 1) and secure with fence assembly pin (fig 6 - 14) by inserting through hinge tubes.

NOTE: The lock handle 8mm (15) is supplied pre-assembled to the front fence (3).

4.10. ATTACHING THE BACK FENCE

4.10.1. Position back fence (fig 7 - 4) along back edge of bed (fig 7 - 1) and secure with fence assembly pin (fig 6 - 14) by inserting through hinge tubes.

NOTE: The lock handle 8mm (15) is supplied pre-assembled to the back fence (4).





4.11. RAISING THE SIDE AND END FENCES

4.11.1. To raise and lock side fence lift front fence (3) and move the lock handle 8mm (fig 8 - 15) into the vertical position (fig 8).

4.11.2. Raise the adjacent side fence so that the lock handle 8mm (fig 8 - 15) passes through the slotted tongue on the side fence.

4.11.3. Lower the handle downwards to lock fences into position (fig 9).

4.11.4. Repeat for all other corners.



5. TRUCK OPERATION

- × **DO NOT** overload the truck. Ensure the load is evenly distributed before use.
- **WARNING!** On inclined surfaces and cornering, be aware of possible load shifting.
- ✓ When pulling the truck proceed at a safe speed.
- ✓ Chock the wheels if the truck is left loaded and unattended.
- ✓ When using as a flat bed truck remove the fence assembly pins, side and end fences and store in safe place.
- × **DO NOT** transport loads with an excessive overhang when using as a flat bed truck.
- **WARNING!** Truck turning circle will be restricted unless all the fence panels are removed when used as a flat bed truck.



6. MAINTENANCE

- 6.1. Regularly check the condition of the tyres and keep the tyres inflated to the specified pressure.
- 6.2. Wash / clean the truck using a mild detergent.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. Please note that other versions of this product are available. If you require documentation for alternative versions, please email or call our technical team on technical@sealey.co.uk or 01284 757505.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk