

baridi

**Baridi Portable Induction Hob: Single Zone, 2000W
10 Power Settings, Timer Function, Black**



Model No. DH145

Thank you for purchasing a Dellonda product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

Important Information

Please read these instructions carefully. Note the safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.



Refer to
instruction
manual



Warning:
Do not cover



Warning:
Hot
Surface



Warning:
Indoor use only

Specification

Cable Length: 1.5m
Colour: Black
Installation: Countertop
Number of Hobs: 1
Power: 2000W
Product Dimensions (W x D x H): 290 x 355 x 70mm
Supply: 220-240V
Type: Induction

Safety Instructions

- ❑ **WARNING!** The warnings, cautions and instructions in this manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be applied by the operator.

1.1. ELECTRICAL SAFETY

- ❑ **WARNING!** It is the user's responsibility to check the following:
Check all electrical equipment and appliances to ensure that they are safe before using. Inspect power supply leads, plugs and all electrical connections for wear and damage. Sealey recommend that an RCD (Residual Current Device) is used with all electrical products. You may obtain an RCD by contacting your local Sealey stockist.

If the product is used in the course of business duties, it must be maintained in a safe condition and routinely PAT (Portable Appliance Test) tested.

Electrical safety information, it is important that the following information is read and understood.

- 1.1.1. Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.
- 1.1.2. Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that they are secure.
- 1.1.3. **IMPORTANT:** Ensure that the voltage rating on the appliance suits the power supply to be used and that the plug is fitted with the correct fuse - see fuse rating in these instructions.
 - × **DO NOT** pull or carry the appliance by the power cable.
 - × **DO NOT** pull the plug from the socket by the cable. Remove the plug from the socket by maintaining a firm grip on the plug.
 - × **DO NOT** use worn or damaged cables, plugs or connectors. Ensure that any faulty item is repaired or replaced immediately by a qualified electrician.
- 1.1.4. This product is fitted with a BS1363/A 13 Amp 3 pin plug.
If the cable or plug is damaged during use, switch the electricity supply and remove from use.
Replace a damaged plug with a BS1363/A 13 Amp 3 pin plug. If in doubt contact a qualified electrician.


Class II products are wired with live (brown) and neutral (blue) only are marked with the Class II symbol;



- A) Connect the BROWN live wire to the live terminal 'L'.
- B) Connect the BLUE neutral wire to the neutral terminal 'N'.
- C) After wiring, check that there are no bare wires and ensure that all wires have been correctly connected.

Ensure that the cable outer sheath extends inside the cable restraint and that the restraint is tight.
DO NOT connect either wire to the earth terminal.

Sealey recommend that repairs are carried out by a qualified electrician.



1.2. GENERAL SAFETY

- ❑ **WARNING!** Disconnect hob from the mains power supply before carrying out any servicing or maintenance.
- ✓ Disconnect the hob from the power supply before handling or cleaning.
- ✓ Maintain the hob in good order and clean condition for best and safest performance.
- ✓ Replace or repair damaged parts. Use genuine parts only. Unauthorised parts may be dangerous and will invalidate the warranty.
- ✓ Ensure there is adequate lighting and keep the immediate area in front of the outlet grille clear.
- ✓ Only use the hob standing on its feet in the upright position.
- ✓ Place heat resistant mat underneath the hob to avoid damage to counter, table top or work surface.
- × **DO NOT** allow any untrained persons to use the hob. Ensure they are familiar with the controls and hazards of the hob.
- × **DO NOT** let power lead hang over an edge (i.e. table), or touch a hot surface, lie in hob hot air flow, or run under a carpet.
- × **DO NOT** touch the top of the hob during and immediately after use as it will be hot.
- × **DO NOT** place the hob near items that may be damaged by heat.

- × **DO NOT** place hob too close to yourself or any object, allow the air to circulate freely. Maintain a minimum air gap of 250mm.
- × **DO NOT** use the hob for any purpose other than that for which it is designed.
- × **DO NOT** stand hob on carpets, cloth, cardboard or fibrous materials when in use.
- × **DO NOT** use the hob outdoors. These hobs are designed for indoor use only.
- × **DO NOT** use hob if the power cord, plug or the hob is damaged, or if the hob has become wet.
- × **DO NOT** use in bathroom, shower room, or in any wet or damp environments or where there is high condensation.
- × **DO NOT** operate the hob when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- × **DO NOT** allow the hob to get wet as this may result in an electric shock and personal injury.
- × **DO NOT** insert or allow objects to enter any openings of hob as this may cause an electric shock, a fire or damage to the hob.
- × **DO NOT** use the hob where there are flammable liquids, solids or gases such as petrol, solvents, aerosols etc, or where heat sensitive materials may be stored.
- × **DO NOT** place the hob immediately below any electrical outlet.
- × **DO NOT** cover hob when in use, and do not obstruct the air vents (i.e. with clothing, curtain, furniture, bedding etc).
- ✓ Allow the hob to cool before storage. When not in use, disconnect from the mains power supply and store in a safe, cool, dry, childproof area.

NOTE: Children of less than 3 years should be kept away unless continuously supervised.

Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.

Operation




fig.1

Item	Description
1	Max: To run at highest power/temperature.
2	Min: To run at lowest power/temperature.
3	Power control mode indicator.
4	Temperature control mode indicator.
5	Timer control mode indicator.
6	Decrease power, temperature or timer setting.
7	LED Display.
8	Increase power, temperature or timer setting.
9	Mode selector - press to cycle through options.
10	On/Off button.

• Power / Temperature ranges

Power (W)	200	400	600	800	1000	1200	1400	1600	1800	2000
-----------	-----	-----	-----	-----	------	------	------	------	------	------

Temp °C	60	80	100	120	140	160	180	200	220	240
---------	----	----	-----	-----	-----	-----	-----	-----	-----	-----

- **NOTE:** Suitable cookware consists of pots and pans with a base made of steel or cast iron. You can identify these either by means of the markings on the pan or by ascertaining whether a magnet clings to the base of pan.
- **NOTE:** Unsuitable cookware is made from any kinds of material that is non-magnetic, such as aluminium, copper and stainless steel, as well as non-metal vessels made of porcelain, glass, ceramic, plastics etc. If unsuitable cookware is placed on the hob, "E0" appears in the **LED**.
- **NOTE:** Thin pan bases are better suited to induction cooking than thick sandwich bases, The very short response times to setting modifications (short preheating period, rapid and controllable browning) are not possible when pans with thick bases are used.
- **NOTE:** Only use cookware that is suitable for the size of the hob. This will ensure that the induction hob function works perfectly. The base of the pan may not be curved or uneven, it must sit flat.
- **NOTE:** The diameter may not be less than 16cm to ensure that the energy field has an effect. **DO NOT** use pans with a diameter in excess 26cm.
- Use the "CONTROL" button (fig.1.9) to select the mode required i.e. power, temperature or timer setting. The relevant **LED** will light (fig.1.3, 1.4, 1.5) to show which mode is active.
- Use the "+, -" buttons (fig.1.6, 1.8) to adjust the setting accordingly.
- **NOTE:** The hob controls can be locked by pressing the "Max" and "Min" buttons simultaneously, repeat to unlock the controls (fig.1.1. fig.1.2).

Maintenance

- Before starting any cleaning or maintenance, ensure the power supply disconnected and the hob plate is completely cooled.
- Clean the hob with a damp cloth or sponge.
- × **DO NOT** wash the hob with water directly.
- × **DO NOT** clean with abrasive sponges or chemical detergents.
- Avoid any surface friction between the pots and cooking plate.

Error codes

Error code	Possible Cause	Solutions
E0	There is no vessel on the respective hob . The vessel is not suitable for induction hobs.	Place a suitable vessel on the respective hob.
E2	The temperature sensor beneath the hob is defective or there is a short circuit	Disconnect the plug from the mains power socket and contact the customer service department .
E3	Voltage supply is too high.	Check and ensure that the cooker is connected to a properly installed mains power socket with 220-240V,50/60hz.
E4	The cooker is not being supplied with enough voltage.	Check and ensure that the cooker is connected to a properly installed mains power socket with 220-240V, 50/60hz.
E5 or E6	The cooker has overheated .	Disconnect the plug from the mains power socket and wait until the cooker has cooled down. If the problem remains, seek advice from a qualified engineer.

Environment Protection and Waste Protection and Electrical Equipment Regulations (WEEE)

Recycle unwanted packaging materials. When this product is no longer required, or has reached the end of its useful life, please dispose of it in an environmentally friendly way. Drain any fluids (if applicable) into approved containers, in accordance with local waste regulations. Under the Waste Batteries and Accumulators Regulations 2009, Dellonda would like to inform the user that this product contains one or more batteries. It is our policy to continually improve products and we reserve the right to alter data, specifications and parts without prior notice. No liability is accepted for incorrect use of this product. Guarantee is 12 months from purchase date, proof of which is required for any claim.

Dellonda Limited, Sole UK Distributor of Baridi

Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757575



support@dellonda.co.uk



www.dellonda.co.uk