



# LOCKING WHEEL NUT REMOVAL SET 10pc

MODEL NO: **SX272.V2**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Wear eye protection



Wear protective gloves

## 1. SAFETY


- WARNING! DO NOT** use the tool if damaged or thought to be faulty.
- WARNING!** Ensure that Health & Safety, Local Authority Regulations and general workshop practice Regulations are adhered to when using tools.
- WARNING!** If jacking up a vehicle refer to manufactures instructions for vehicle and jack.
- \* **DO NOT** use the tool for a task it is not designed to perform.
- \* **DO NOT** use worn, or damaged sockets.
- \* **DO NOT** use the tool unless you have been instructed in its use by a qualified person.
- \* **DO NOT** operate the tool if you are tired or under the influence of alcohol, drugs or intoxicating medication.
- ✓ Maintain the tool in good condition.
- ✓ Follow all workshop safety rules, regulations and conditions.
- ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non-slip shoes.
- ✓ Keep children and non essential persons away from the working area.

## 2. INTRODUCTION

Conical shaped design allows socket to fit over locking/wheel nut. Socket is hammered onto nut using the punch, so nut and socket wedge together. Nut can then be removed with a breaker bar or impact wrench. Set also includes drift to remove nut from socket.



## 3. SPECIFICATION

Model No:.....**SX272.V2**  
 Drive: .....19mm and 22mm Hex Drive  
 19mm Maximum Internal Sizes: ..... Ø18, 19, 20, 21mm  
 22mm Maximum Internal Sizes ..... Ø23, 24, 25mm



## 4. OPERATION

- 4.1. Select the appropriate removal socket to create a tight fit over the wheel nut.
  - 4.2. Fit the socket over the wheel nut and insert the punch (fig.1).
  - 4.3. Using a suitable hammer, strike the punch sharply several times until the socket has gripped the wheel nut.
  - 4.4. Place either a wrench or impact socket over the hex at the rear of the removal socket.
  - 4.5. Release the wheel nut by turning as a unit with the removal socket.
  - 4.6. Hold the removal socket in a vice and pass the drift through the rear end of the socket and strike the drift to release the wheel nut (fig.2).
- WARNING:** Take care when removing the nut from the removal socket: the nut can exit the socket with considerable force.



## 5. MAINTENANCE

- 5.1. Clean the inside of the socket with abrasive paper or cloth to remove any dirt or irregularity.
- 5.2. Keep the kit clean and store all the components in the case after use.



### ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Important:** No Liability is accepted for incorrect use of this product.

**Warranty:** Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk