



UNDER VEHICLE ENGINE/GEARBOX SUPPORT

- FIXED

MODEL NO: VS0111

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to
instructions



Wear eye
protection



Wear protective
gloves



Wear safety
footwear

1. SAFETY

- ✓ Ensure that the engine support is in good working order. Take action for immediate repair or replacement of damaged parts.
Use genuine parts only. The use of unauthorised parts may be dangerous and will invalidate the warranty.
- ✓ Locate the vehicle in a suitable, well lit work area.
- ✓ Keep work area clean and tidy and free from unrelated materials.
- ✓ Ensure the vehicle handbrake is engaged and the engine/motor is switched off.
- ✓ Ensure all non-essential persons keep a safe distance whilst the engine support is in use.
- ✗ **DO NOT** use the engine support if damaged.
- ✗ **DO NOT** allow untrained persons to operate the engine/gearbox support.
- ✗ **DO NOT** use the support for purposes other than that for which it is designed.
- ✗ **DO NOT** exceed the rated capacity of the engine support.
- ☐ **WARNING!** Ensure that the vehicle structure being used to anchor the support is in sound condition.
- ✓ When not in use, store engine support in a safe, dry, childproof area.

IMPORTANT: These instructions are provided as a guide only. Always refer to the vehicle manufacturer's service instructions, or a proprietary manual to establish the current procedure and data.

- ☐ **WARNING:** The warnings, cautions and instructions in this manual cannot cover all possible conditions and situations that may occur. It must be understood that common sense and caution are factors which cannot be built into this product but must be applied by the operator.

2. INTRODUCTION

Designed to support the engine or gearbox when mountings or gearbox are being removed. Ideal when replacing clutches or timing belts. Removes the need for using a transmission jack or engine support beam. Adjustable Cross Beam making the unit suitable for most transverse and in-line configurations. Fitted by suspending underneath the vehicle using support hooks which counter-balance against the underside of the vehicle.

3. SPECIFICATION

Model No: VS0111
Maximum Capacity: 400kg
Weight: 10.5kg
Length: 1000mm
Width: 500mm
Maximum Crossbeam Supporting Foot distance: 450mm




4. ASSEMBLY AND OPERATION

Numbers below in brackets refer to those on Parts Information sheet attached to this manual.

- 4.1. Assemble as shown on attached Parts Information. Note: correct orientation of j-bolt assembly, fig.1 overleaf.
- 4.2. With the vehicle elevated on a lift, lay the assembled support on the floor beneath to set it to approximate size.
- 4.3. Wind the support pad (12) down to allow clearance when fitting.
- 4.4. The spacer, j-bolts (13, 18, 19, 16, 17) are designed to hook over or through the main crossmember.
- 4.5. Offer up to the vehicle and locate by swinging the j-bolts over a crossmember to suspend the support assembly.
- 4.6. Take care not to trap any pipes or wiring.
- 4.7. Tighten the j-bolt tensioner knobs (17) to bring the support up to the chassis, making sure that the j-bolts are firmly located and not likely to slip.
- 4.8. Bring the threaded rods (1, 2) to a suitable point on the floorpan and screw them into light contact. Take care that the area of floorpan selected is in sound condition. Lock short beam (3) in position using knobs (5, 7).
- 4.9. Raise the support pad (12) carefully under the gearbox/engine using a spanner on the hex domed nut (11).
- 4.10. When the required support has been achieved, securely lock the support pad in position using the upper and lower lock nuts (10, 11).
- 4.11. When the task is finished, remove the unit in the reverse of the installation procedure. Make sure that it is removed before lowering.

5. MAINTENANCE

- 5.1. To ensure reliable operation, clean the unit regularly with a damp, clean cloth and warm water. **DO NOT** use solvents or detergents as these may permanently damage the item. Replace any missing parts only with originals (see parts list for item numbers)
- 5.2. Confirm all components are in situ and working correctly.
- 5.3. **STORAGE**
- 5.3.1. Before storing the unit in its original packaging, confirm all components are in situ and working correctly. Ensure unit is clean and dry.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR
PURCHASE HERE

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Tel: 01284 757500 • Email: sales@sealey.co.uk • Web: www.sealey.co.uk