



INSTRUCTIONS FOR:

AXLE STAND 3 TONNE RATCHET TYPE

MODEL No: **VS1003**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions and maintained properly, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to Instruction Manual








1. SAFETY

❑ WARNING!

DO NOT OVERLOAD AXLE STANDS BEYOND RATED CAPACITY. OVERLOADING CAN CAUSE DAMAGE TO, OR FAILURE OF, THE AXLE STANDS. POSITION LOAD ON CENTRE OF CRUTCH/SADDLE ONLY. ALWAYS USE STANDS IN PAIRS ON HARD LEVEL SURFACE CAPABLE OF SUSTAINING THE LOAD. USE OF STANDS ON OTHER THAN HARD LEVEL SURFACES CAN RESULT IN LOAD INSTABILITY AND POSSIBLE LOSS OF LOAD. DO NOT USE ON TARMACADAM. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN DAMAGE TO AXLE STANDS, LOSS OF LOAD RESULTING IN PROPERTY DAMAGE, SERIOUS PERSONAL INJURY OR LOSS OF LIFE.

▲ DANGER! GREAT CARE MUST BE TAKEN TO ENSURE YOU LOWER THE VEHICLE (OR OTHER LOAD) SLOWLY AND CAREFULLY ONTO THE CENTRES OF THE CRUTCH/SADDLE OF THE AXLE STANDS.

- ✓ Use only as specified by the manufacturer.
- ✓ Ensure the load does not exceed the maximum capacity as marked on the axle stand, per pair.
- ✓ Use no more than a single pair of stands either on the front, rear or one side of the vehicle. Use in pairs.
- ✓ No alterations or modifications shall be made to this product.
- ✓ Use on a hard, level surface, e.g. concrete. **DO NOT** use on uneven ground or tarmacadam.
- ✓ Securely chock wheels in contact with the ground. Before jacking and placing the stands, apply vehicle handbrake (put automatics in 'Park').
- ✓ Make sure that each stand is securely located under a strong point on the vehicle; consult the vehicle manufacturer's handbook for guidance. Ensure that height adjust locking mechanism is fully located before applying any load to the axle stand.
- ✓ Ensure that the load is located centrally on the saddle, and that the weight is directed through the vertical axis of the stand.
- ✓ Exercise extra care when using with a three wheeled vehicle or a trailer. Refer to vehicle manufacturer's instructions.
- ✓ Once vehicle is supported, ensure that the vehicle and stands are stable before starting work. Ensure that it is not possible for the vehicle to move before commencing any work.
- ✓ Inspect stands before each use. **DO NOT** use if they show signs of damage. **DO NOT** use if it is suspected that they have been overloaded.
- ✓ Before commencing any work or going beneath the vehicle, undertake a risk assessment. Ensure that a responsible person is aware of the work about to be undertaken.
- ✓ Replace any labels on the axle stand should they become unreadable. This applies in particular to any warning or operation instruction labels. If replacement labels are required, contact your Sealey stockist.
- * **DO NOT** use axle stands on the highway, or anywhere else if it is deemed to be unsafe.
- * **DO NOT** push or twist the vehicle/load whilst it is supported on stands.
- * **DO NOT** mix components between stands. Use only as supplied.
- * **DO NOT** allow children or animals in the vicinity of a vehicle supported on axle stands.
- * **DO NOT** leave a vehicle on axle stands in an area that could be considered a hazard to others or property.
- ✓ **FOLLOW STEPS 1, 2 AND 3 TO CORRECTLY PLACE VEHICLE/LOAD ONTO AXLE STANDS**



2. INTRODUCTION

Ratchet type axle stands with cast iron support posts. Feature angled teeth in posts, which prevent accidental release of load - the more weight applied, the tighter the post is locked.

3. SPECIFICATION

Capacity (each): 3 tonnes (3,000 kg)
Capacity (pair): 6 tonnes (6,000kg)
Minimum Height: 287mm
Maximum Height: 427mm

4. PREPARATION



- 4.1. Insert centre column into base of axle stand (Fig.2). Ensure toothed side of column will engage with locking lever mechanism.
- 4.2. Bend in locking tab using a small chisel and hammer (Fig.1).
- 4.3. Check axle stand is in good condition and has not suffered damage during transit.

5. OPERATION

- 5.1. Refer to vehicle's handbook for correct jacking procedure. Check to ensure manufacturer's recommended jacking points are in good condition.
 - 5.2. Position axle stands under jacking points.
 - 5.3. To adjust axle stands: Hold locking lever up, while lifting column to required height. Push locking lever down to lock pawl into column teeth (Fig.2).
- WARNING! ENSURE PAWL IS FULLY ENGAGED WITH TEETH.**
- 5.4. Lower vehicle onto axle stands carefully and slowly. Ensure load bearing points sit in the centre of the saddles and that the axle stands are stable.
Also ensure that there are no objects or persons that could impede the safe lowering of the vehicle onto the stands.
- ▲ **DANGER!** You must follow instructions carefully and ensure you **DO NOT** load the axle stands off-centre. Failure to heed these warnings may cause damage, injury or loss of life.

6. MAINTENANCE & INSPECTION

- 6.1. Before each use, check that the axle stands and the stand's welds are not cracked and that there are no missing or damaged parts.
Any suspect axle stand must be removed from service immediately.
- 6.2. Due to the potential hazards associated with these axle stands, do not misuse, or make any modification to the axle stands or components.
- 6.3. It is the responsibility of the owner to ensure that the operator has read these instructions together with the safety features on the side of the axle stand and that the operator is familiar with the axle stand's use and limitations.



Parts support is available for this product. To obtain a parts listing and/or diagram, please log on to www.sealey.co.uk, email sales@sealey.co.uk or telephone 01284 757500.

Environmental Protection



Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal of it according to local regulations.

NOTE: It is our policy to improve products continually and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.



Sole UK Distributor, Sealey Group,
Kempson Way, Suffolk Business Park,
Bury St. Edmunds, Suffolk,
IP32 7AR



01284 757500

01284 703534



www.sealey.co.uk

sales@sealey.co.uk