

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Read instructions before use



Wear eye protection



Wear ear protection



Wear protective gloves



Wear a mask



Wear safety footwear

NOTE: These instructions are for online only and will not be provided with the product.

1. SAFETY

- ❑ **WARNING!** If used incorrectly, this product can cause damage or injury to the operator. Ensure all instructions are read and understood before using this product.
- ❑ **Cutting discs should be used for cutting, grinding discs should be used for grinding and carving discs should be used for carving.**
 - ✓ Always wear safety glasses, ear protection, gloves and dust mask when using cutting, grinding and carving discs.
 - ✓ Ensure there is a safety guard in place before operating the machine.
 - ✓ Ensure the work area is well-ventilated and well lit.
 - ✓ Use the correct type of disc for the job you are doing.
 - ✓ Keep your hands away from the disc.
 - ✓ Ensure the tool and disc are compatible, and suitable for the task at hand by following all markings.
 - ✓ Check the spindle speed of the machine is no higher than the operating speed marked on the disc.
 - ✓ Turn off the power before changing the disc.
 - ✓ Disconnect the power cord from the outlet before making any adjustments to the tool.
 - ✗ **DO NOT** use discs if they are cracked, chipped, or damaged in any way.
 - ✗ **DO NOT** overload the disc.
 - ✗ **DO NOT** use the disc if it is not spinning freely.

2. INSTRUCTIONS

- 2.1. Disconnect the power cord from the outlet before mounting/removing the disc from the angle grinder.
- 2.2. Attach the disc to the angle grinder as per grinder instructions. Make sure the disc is properly seated and tightened.
- 2.3. Turn on the angle grinder and allow the disc to come up to speed.
- 2.4. Start cutting or grinding slowly and gradually increase speed as needed.
- 2.5. Apply even pressure to the disc. **DO NOT** force the disc to cut or grind.
- 2.6. Keep your hands away from the disc.
- 2.7. When you are finished, turn off the angle grinder and allow the disc to come to a complete stop.

3. MAINTENANCE

- ✓ Using a sharp disc will generate the best results.
- ✓ Replace the disc when it is worn out or damaged.
- ✓ Store the disc in a dry, cool place.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR PURCHASE HERE

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



sales@sealey.co.uk



www.sealey.co.uk