



50/75TONNE FLOOR TYPE HYDRAULIC PRESS

MODEL NO: YK509F.V2, YK759F.V3

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Wear eye protection



Wear protective gloves



Wear safety footwear

1. SAFETY

1.1. GENERAL SAFETY

- ✓ Familiarise yourself with this products application and limitations, as well as the specific potential hazards peculiar to the press.
- ✓ Maintain the press in good condition (use an authorised service agent).
- ✓ Replace or repair damaged parts. Use recommended parts only. Non authorised parts may be dangerous and will invalidate the warranty.
- ✓ Keep the press clean for best and safest performance.
- ✓ Locate the press in a suitable working area for its function, keep area clean, tidy, free from unrelated materials and ensure there is adequate lighting.
- ✓ Ensure the workpiece is correctly secured before operating the press.
- ☐ **WARNING!** Always wear approved eye or face protection when operating the press.
- ✓ Remove ill fitting clothing. Remove ties, watches, rings, loose jewellery and contain long hair.
- ✓ Keep hands and body clear of the work table when operating the press.
- ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non slip steel toe-capped shoes/boots.
- ✓ Keep children and unauthorised persons away from the working area.
- ✗ **DO NOT** operate the press if any parts are missing as this may cause failure or possible personal injury.
- ✗ **DO NOT** use to compress springs or any other item that could disengage and cause a potential hazard.
- ✗ **DO NOT** stand directly in front of the loaded press and never leave a loaded press unattended.
- ✗ **DO NOT** force the press to achieve a task it was not designed to perform.
- ✗ **DO NOT** make any modifications to the press.
- ✗ **DO NOT** adjust or tamper with the safety valve.
- ✗ **DO NOT** exceed the rated capacity of the press.
- ✗ **DO NOT** apply off centre loads.
- ✗ **DO NOT** allow the workpiece or the arbor plates to fall from the press working bench.
- ✗ **DO NOT** get the press wet or use in damp or wet locations or areas where there is condensation.
- ✗ **DO NOT** operate the press when you are tired, under the influence of alcohol, drugs or intoxicating medication.
- ✓ When not in use release pressure from the pump and clean the press. Stand or store the arbors in a safe location.
- ☐ **WARNING!** Always position the press against a wall. If the press is situated in the open workshop, it is essential that a guard be placed at the rear of the unit. This will prevent injury to bystanders in the event of the work piece ejecting suddenly.
- ☐ **WARNING!** The warnings, cautions and instructions in this manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be applied by the operator.
- ▲ **DANGER!** The press is top heavy. If it requires moving after assembly or for relocation, use suitable slings around the top crossbeam, or lift direct with a forklift with the forks located under the top crossbeam. **DO NOT** use a pallet truck.

2. INTRODUCTION

Steel frame construction with hydraulic pump unit. Sliding hydraulic ram assembly with lateral travel for off-centre pressing applications. Fitted with ram pressure gauge. Supplied with flat pressing plate/V-blocks.

3. SPECIFICATION



Model no YK509F.V2
 Capacity 50tonne
 Lateral ram travel 245mm
 Max. height - ram to table 1047mm
 Min. height - ram to table 67mm
 Optional accessories
 YKSG50 - Safety Guard, YKPP8 - Press Pin Set
 Overall height..... 1877mm
 Ram diameter Ø75mm
 Ram stroke..... 200mm
 Table aperture 235/185mm
 Typehydraulic
 Working table depth 259mm
 Working table width..... 910mm

Model no YK759F.V3
 Capacity 75tonne
 Lateral ram travel 260mm
 Max. height - ram to table 884mm
 Min. height - ram to table 170mm
 Optional accessories
 YKSG75 - Safety Guard, YKPP8 - Press Pin Set
 Overall height..... 1925mm
 Ram diameter Ø93mm
 Ram stroke..... 250mm
 Table aperture 251/201mm
 Typehydraulic
 Working table depth 279mm
 Working table width..... 1020mm

4. ASSEMBLY

Numbers refer to attached Parts List

- 4.1. Remove any loose items from the crate. Attach slings around the top cross member, using a suitable hoist or gantry lift the framework out of the transportation crate into an upright position.
- 4.2. Attach base sections (65) and (66) and supports (03) to the left and right posts using appropriate fasteners.
- 4.3. Move the winch (21) to the outside of the left hand post (position A on the Parts List) and attach using appropriate fasteners. Ensure that the cables are located correctly in the rollers before fully tightening.
- 4.4. Bolt pump assembly (64) to the top of the frame.
- 4.5. Connect pump assembly.
- 4.5.1. Connect short hose (52) to pump. Remove blanking plug from pump connection (45), see fig.1.
- 4.6. Fit air hose (61).
- 4.6.1. Undo nut and remove blanking plug from end of the pipe, see fig.2. Place nut over pipe. Push on air hose (61). Tighten nut.
- 4.6.2. Transit plug must be open in use. Only to be in closed position for transit.
- 4.7. Fit gauge (58).
- 4.7.1. Remove transit bolt from end of gauge fitting (57) and use PTFE tape to seal correctly.
- 4.8. Fit handles (70, 71) onto pump (64).
- 4.9. Fit carry handle (73).



5. INSTALLATION

- 5.1. Securely attach the press to a flat, firm, level surface taking into account clearance for working pieces. Ensure surface is capable of withstanding weight of press and workpieces.
 - ▲ **DANGER!** The press is top heavy. If it requires moving after assembly or for relocation, use suitable slings around the top crossbeam, or lift direct with a forklift with the forks located under the top crossbeam. **DO NOT** use a pallet truck.
- 5.2. **PURGE HYDRAULIC SYSTEM**

Before operating the press, the hydraulic system may require purging in order to eliminate any air that may have built up during transit. Open the release valve by turning anti-clockwise and pump the handle several times.

Should the system malfunction at any time, repeating this procedure may resolve the problem.

 - ▲ **DANGER!** Presses are purpose designed to withstand greater loads than the hydraulic units can develop. For safety reasons, always ensure the workpiece is secured on the table to ensure loads that flex will not suddenly "give" causing danger to operator or damage to component. Ensure you have read and understood chapter 1 Safety Instructions.

6. OPERATION

- 6.1. Set the bed frame at the desired height, if adjustment is required, turn the hand winch until the cable just takes the weight of the bed frame, remove the safety clips (26) from the back of the pins (27), and withdraw the pins. Use the hand winch to raise or lower the bed frame to the height required, insert pins and safety clips. Slacken off the hand winch so that the pins are taking the full weight of the bed frame.
- 6.2. Check that the release valve on the hydraulic unit is fully closed, ready for operation.
- 6.3. Locate the flat pressing plates or the v-blocks on to the bed frame, push down the locating pins to ensure the plates do not slip. Place workpiece onto the plates and position the head of the hydraulic unit on the centre of the workpiece using an appropriate extension.
 - Note:** Care must be taken to ensure the plates do not fall from the bed frame.
- WARNING! DO NOT** apply off centre loads.
- 6.4. When work is complete turn the release valve anti-clockwise to release the pressure and the piston and the ram head will retract automatically. **Note:** Always keep the piston retracted after use.

7. MAINTENANCE

Note: Maintenance and repair must only be carried out by qualified person. Contact your Sealey stockist for details.

- 7.1. Always keep the press clean, dry and lubricate all moving parts at regular intervals.
- 7.2. When not in use always store in a dry location with the piston retracted.

7.3. Should you need to check or replace oil ensure piston is fully retracted. Remove the transit plug, see fig.2 and top up using Sealey hydraulic jack oil. **DO NOT** use brake fluid. Contact your local Sealey stockist for details. After filling purge the system to remove any air.

IMPORTANT: NO RESPONSIBILITY IS ACCEPTED FOR INCORRECT USE OF THE PRESS.

Hydraulic products are only repaired by local service agents. We have service/repair agents in all parts of the UK.

DO NOT RETURN PRODUCT TO US. Please telephone us on 01284 757500 to obtain the address and phone number of your local agent. If product is under guarantee please contact your stockist.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. Please note that other versions of this product are available. If you require documentation for alternative versions, please email or call our technical team on technical@sealey.co.uk or 01284 757505.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk