

Vehicle Graphic

application instructions

Order Refs. POS/ST/VAN/A 460mm x 460mm
POS/ST/VAN/B 610mm x 610mm



Preparation

The vehicle panel onto which you are applying the graphic must be clean, dry and free of grease.

Methylated spirits is recommended as a final preparation as it evaporates quickly without leaving any residue on the surface.

Application

- 1 Use masking tape to hold the graphic whilst measuring to a horizontal line (a panel edge or 'crease' line can be helpful).
- 2 When in desired position, run masking tape along top edge of graphic to create a 'hinge'.
- 3 Lift the graphic up from the bottom edge taking care not to displace the 'hinge'. Carefully begin to peel away the backing paper from the top and simultaneously, using a squeegee, begin to rub down the graphic onto the surface. Work from the top and centre downwards and outwards using a reasonable amount of pressure and overlap strokes to ensure that no air bubbles remain.
- 4 Remove masking tape.

Masking tape 'hinge'



Apply pressure downwards and outwards

