



| Item | Part No. | Description |
|------|------------|---|
| 1 | SMIG140.27 | Handle |
| 2 | 140XT.02 | Case |
| 3 | 140XT.03 | Back Panel |
| 4 | 140XT.04 | Fan |
| 5 | 140XT.05 | Bottom Panel |
| 6 | 140XT.06 | Front Panel |
| 7 | 250XTD.28 | Cable Holder |
| 8 | 140XT.08 | Work Clamp |
| 9 | 140XT.09 | Electrode Holder Cable |
| 11 | 140XT.11 | Switch, Rocker (Red) - T125 - 16(4)A / 250V |
| 12 | 140XT.12 | Indicator |
| 13 | 140XT.13 | Hand Wheel |

| Item | Part No. | Description |
|------|-------------|--|
| 14 | 140XT.14 | Pointer |
| 15 | 140XT.15 | Shunt Bracket |
| 16 | 140XT.16 | Shunt |
| 17 | 180XT.14 | Top Cover |
| 18 | 140XT.18 | Lead Screw Pin |
| 19 | 140XT.19 | Heat Relay |
| 20 | 140XT.20 | Heat Conductor |
| 21 | 140XT.21 | Transformer |
| 22 | 140XT.22 | Transparent Plate |
| 23 | 140XT.23 | Frame |
| -- | 140XT.V2-24 | Heat Relay (Not Shown) |
| -- | 140XT.24 | Chipping Hammer/Wire Brush (Not Shown) |

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.