



Item	Part No.	Description
1	180XT.01	Bottom case
2	250XTD.28	Cable holder
3	250XTD.24	Dinse Socket
4	140XT.11	Switch, rocker(red) - T125 - 16(4)A / 250V
5	180XT.05	Indicator light (yellow)
6	180XT.06	Shunt support upright
7	180XT.07	Regulator handwheel
8	180XT.08	Indicator
9	180XT.09	Shunt
10	140XT.17	Clip
11	140XT.18	Lead screw pin
12	180XT.12	Thermal relay
14	180XT.14	Top cover
15	250XTD.11	Handle

Item	Part No.	Description
16	140XT.22	Transparent plate
17	250XTD.13	Handle extension
18	180XT.18	Transformer
19	180XT.19	Fan
20	250XTD.06	Nylon cover
21	180XT.21	Back panel
22	180XT.22	Nylon bush
23	180XT.23	Wheel axle: Solid, circlip fittings
24	180XT.24	Wheel, fixed plastic (D:138 W:32 B:8)
--	180XT.25	Plastic frame (Not Shown)
--	180XT.ACC1	Electrode holder (Not Shown)
--	180XT.ACC2	Earth clamp (Not Shown)
--	180XT.ACC3	Eaelectrode holder with cable (Not Shown)
--	180XT.ACC4	Earth clamp with cable (Not Shown)

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.