




Parts Information:
Space Warmer® Paraffin, Kerosene & Diesel Heater 157,000Btu/hr with
Wheels
Model No: AB160P



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk



Parts Information:
Space Warmer® Paraffin, Kerosene &
Diesel Heater 157,000Btu/hr with Wheels
Model No: AB160P

| Item | Part No. | Description |
|------|-----------|------------------------|
| 1 | AB160P.01 | Combustion Chamber |
| 2 | AB160P.02 | Upper Body |
| 3 | AB160P.03 | Lower Body |
| 4 | AB125P.04 | Support Bracket (Left) |
| 5 | AB160P.05 | Motor |
| 6 | AB125P.06 | Capacitor |
| 7 | AB160P.07 | Motor Support |
| 8 | AB125P.08 | Power Lead Hook |
| 9 | AB125P.09 | Cable Protection |
| 10 | AB160P.10 | Fan Protection Ring |
| 11 | AB160P.11 | Fan |
| 12 | AB125P.12 | Plate |
| 13 | AB160P.13 | Grille |
| 14 | AB125P.14 | Pipe |
| 15 | AB70P.12 | Pipe |
| 16 | AB70P.13 | Clamp |
| 17 | AB70P.14 | Fuel Filter |
| 18 | AB70P.15 | Fuel Tube |
| 19 | AB125P.19 | Handle Support |
| 20 | AB70P.51 | Plug |
| 21 | AB125P.21 | Components Drawer |
| 23 | AB160P.23 | Control Panel Box |
| 24 | AB125P.24 | Protection Cable |
| 25 | AB125P.25 | Pipe |
| 26 | AB70P.17 | Nipple 1/4" |
| 28 | AB125P.28 | Drain Plug |
| 29 | AB125P.29 | Fuel Tank |
| 30 | AB70P.19 | Fuel Tank Cap |
| 31 | AB125P.31 | Wheel Axle |
| 32 | FWM20.S | Flat Washer M20 |
| 33 | AB125P.33 | Wheel |
| 34 | AB125P.34 | Wheel Cap |

| Item | Part No. | Description |
|------|-----------|--------------------------------------|
| 35 | AB125P.35 | Wheel Cover |
| 36 | AB70P.27 | Flame Sensor |
| 37 | AB125P.37 | Combustion Head |
| 38 | AB70P.24 | Terminal Board |
| 39 | AB70P.25 | Air Regulator |
| 40 | AB70P.26 | Flame Sensor Support |
| 41 | AB125P.41 | Control Panel |
| 48 | IR55.51 | Control Box |
| 49 | AB125P.49 | Plate for Flame Control Unit |
| 50 | AB125P.50 | Switch, Rocker |
| 51 | AB125P.51 | Thermostat Plug |
| 52 | AB125P.52 | Drain Plug |
| 53 | AB70P.57 | Power Cable |
| 54 | AB125P.54 | Lamp |
| 55 | AB125P.55 | Pump |
| 56 | AB70P.37 | Solenoid Coil |
| 57 | AB70P.38 | Solenoid Pump |
| 58 | AB70P.39 | Nipple 1/4" |
| 59 | AB70P.40 | Coupling |
| 60 | AB70P.41 | Nipple 1/8" |
| 61 | AB70P.42 | Fuel Pipe |
| 62 | AB160P.62 | Nozzle |
| 63 | AB125P.63 | Nozzle Support |
| 64 | AB125P.64 | Burner Disc |
| 65 | SN14.S | Steel Nut M14 |
| 66 | AB70P.47 | Electrode |
| 67 | AB125P.67 | HT Lead |
| 68 | AB125P.68 | Photocell |
| 69 | AB70P.48 | Protection for Photocell |
| 70 | AB125P.70 | Support Bracket (Right) |
| 75 | AB70P.33 | Button Protection |
| -- | ABT04 | Remote Heater Thermostat (Not Shown) |

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk