


Parts Information: Air Brush Kit without Propellant Model No: AB931



Item	Part No.	Description
1	AB931/01	Housing, Right
2	AB931/02	Housing, Left
3	AB931/03	Gravity Cup
4	AB931/04	Cap, Gravity Gun
5	SA912.V2-04	O-Ring
6	AB931/06	Seat, Nozzle
7	AB931/07	Fluid Cap
8	AB931/08	Nozzle, 0.30mm
9	AB931/09	Needle
10	AB931/10	Cap, Nozzle Seat
11	AB931/11	O-Ring
12	AB931/12	Bush
13	AB931/13	Screw
14	AB931/14	Trigger
15	AB931/15	Spring, Trigger
16	AB931/16	Plunger

Item	Part No.	Description
17	AB931/17	Cap
18	AB931/18	O-Ring
19	AB931/19	Cap
20	AB931/20	O-Ring
21	AB931/21	Spring, Plunger
22	AB931/22	Housing, Valve
23	AB931/23	Cap
24	AB931/24	Screw
25	AB931/25	Inlet
26	AB930/19	Air Hose, 5ft. With Coupling
27	AB931/27	Nut, Adjustment Screw
28	AB931/28	Fluid Inlet Screw
29	AB930/11	Regulator Valve/Cap
30	AB931.V2-07	Air Hose Adaptor
--	AB931/25-1	Special Nut (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.