



Item	Part No.	Description
1	AK45KIT.01	Plunger
2	AK45KIT.02	Container Spring
3	AK45KIT.03	Push Seal, Plunger
4	AK45KIT.04	Hexagonal Nut
5	AK45KIT.05	Container Gasket
6	AK45KIT.06	Housing Ring
7	AK45KIT.07	Valve Spring
8	AK45KIT.08	Spring, Conical

Item	Part No.	Description
9	AK45KIT.09	Air Piston Plunger
10	AK45KIT.10	Rotation Plate
11	AK45KIT.11	Trigger (c/w Pin)
12	AK45KIT.12	Gasket
13	AK45KIT.13	Switch, Air Valve
14	AK45KIT.14	Air Fitting
16	AK45KIT.16	Hex Spout
--	AK45KIT.15	Air Vent Valve (Not Shown)

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.