



Item	Part No.	Description
1	BOOST160.01	Lower Panel
2	BOOST140.02	Transformer
3	BOOST180.03	Cable Bushing
4	BOOST180.04	Switch, Rocker (Illuminated)
5	BOOST180.05	Switch, Rocker (White)
6	BOOST180.06	Power Cable
7	BOOST180.07	Positive Clamp + Cable
7A	BOOST180.07A	Negative Clamp + Cable
10	BOOST180.10	Terminal Complete (Pair)
11	START560.03	Fuse Cover
12	BOOST180.12	Ammeter
14	BOOST180.14	Fuse Holder (c/w Fixings)
15	BOOST180.15	Support

Item	Part No.	Description
16	BOOST180.16	Shunt
17	BOOST180.17	Rectifier
18	BOOST160.18	Top Cover
19	BOOST180.19	Handle
20	BOOST160.20	Middle Support
--	BOOST180.08	Cable, Positive (Not Shown)
--	BOOST180.09	Cable, Negative (Not Shown)
--	START180.F	Fuse (Not Shown)
--	START180.F20	Fuse, Pack of 20 (Not Shown)
--	BOOST160.FS	Fuse Set (Not Shown)
--	BOOST160.PP	Panel Parts (Not Shown)
--	CHARGE124.14	Rubber Foot (Not Shown)

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.