



Item	Part No.	Description
1	BT91-7V4-01	Gauge
2	BT91-7V4-02	Top Case (use BT91-7V4-15)
3	BT91-7V4-03	Coil Element
4	BT91-7V4-04	Screw (c/w Nut)
5	BT91-7V4-05	Rocker Switch
6	BT91-7V4-06	Inside Plate (B)
7	BT91-7V4-07	Clamp (Negative)
8	BT91-7V4-08	Clamp Cable (Negative)

Item	Part No.	Description
9	BT91-7V4-09	Clamp Cable Grip
10	BT91-7V4-10	Foot
11	BT91-7V4-11	Clamp Cable (Positive)
12	BT91-7V4-12	Clamp (Positive)
13	BT91-7V4-14	Bottom Case
14	BT91-7V4-15	Handle/Clamp Holder (c/w Part 2)
15	BT91-7V4-16	Grip
16	BT91-7V4-17	Inside Plate (A)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.