



Item	Part No.	Description
1	CHARGE112.01	Top Cover
2	CHARGE124.02	Handle
3	CHARGE112.03	Lower Panel
3A	CHARGE106.03A	Front Panel
4	CHARGE112.04	Ammeter
5	CHARGE124.05	Cable Bushing
6	CHARGE112.06	Positive Clamp
6A	CHARGE112.06A	Negative Clamp
7	CHARGE106.07	Standard Blade Fuse 15Amp

Item	Part No.	Description
8	CHARGE124.08	Switch, Rocker (Illuminated) 30A/250V
9	CHARGE124.09	Switch, Rocker (White) 20A/250V
10	CHARGE124.10	Switch, Rocker (Illuminated, On/Off)
11	CHARGE112.11	Power Cable With Plug
12	CHARGE112.12	Rectifier
13	CHARGE107.13	Main Transformer
14	CHARGE124.14	Rubber Foot
--	CHARGE106.FS	Fuse Set (Not Shown)
--	CHARGE106.PP	Panel Parts (Not Shown)

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.