



Item	Part No.	Description
1	CHARGE106V201	Top Cover
2	CHARGE106V202	Handle Belt
3	CHARGE106V203	Bottom Panel
3A	CH110V2.03A	Front Panel
4	CHARGE106V204	Ammeter
5	CHARGE106V205	Cable Bushing
6	CHARGE112.06	Positive Clamp
6A	CHARGE112.06A	Negative Clamp
8	CHARGE106V208	Voltage Switch, Rocker
9	CHARGE106V209	Switch, White Rocker

Item	Part No.	Description
10	CHARGE106V210	Power Switch, Rocker
11	CHARGE112.11	Mains Cable (c/w Plug)
12	CHARGE112.12	Rectifier
13	CHARGE110V213	Main Transformer
14	CHARGE124.14	Rubber Foot
--	CHARGE112.07	Fuse 30A (Not Shown) (See Catalogue)
--	CHARGE110V216	Positive Cable (Not Shown)
--	CHARGE110V217	Negative Cable (Not Shown)
--	CHARGE124.07A	Fuse Holder (Not Shown)

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.