



Item	Part No.	Description
1	CHARGE112.01	Top cover
2	CHARGE124.02	Handle
3	CHARGE112.03	Lower Panel
3A	CHARGE112.03A	Front Panel
4	CHARGE112.04	Ammeter
5	CHARGE124.05	Cable Bushing
6	CHARGE112.06	Positive Clamp
6A	CHARGE112.06A	Negative Clamp
8	CHARGE124.08	Voltage Switch, Rocker

Item	Part No.	Description
9	CHARGE124.09	Switch, White Rocker
10	CHARGE124.10	Power Switch, Rocker
11	CHARGE112.11	Mains Cable (c/w Plug)
12	CHARGE112.12	Rectifier
13	CHARGE112.13	Main Transformer
14	CHARGE124.14	Rubber Foot
--	CHARGE112.07	Fuse 30A (Not Shown) (See Catalogue)
--	CHARGE112.FS	Fuse Kit (c/w Fuse + Holder) (Not Shown)
--	CHARGE112.PP	Panel Parts (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.