



Item	Part No.	Description
1	CHARGE115V201	Top Cover
2	CHARGE115V202	Handle Belt
3	CHARGE115V203	Lower Panel
3A	CH115V2.03A	Front Panel
4	CHARGE115V204	Ammeter
5	CHARGE106V205	Cable Bushing
6	CHARGE124.06	Positive Clamp
6A	CHARGE124.06A	Negative Clamp
8	CHARGE124.08	Voltage Switch, Rocker

Item	Part No.	Description
9	CHARGE124.09	Switch, White Rocker
10	CHARGE124.10	Power Switch, Rocker
11	CHARGE124.11	Mains Cable (c/w Plug)
12	CHARGE124.12	Rectifier
13	CHARGE115V213	Main Transformer
14	CHARGE124.14	Rubber Foot
--	CHARGE115.07	Fuse 30A (Not Shown) (See Catalogue)
--	CHARGE115.15	Fuse 5A (Not Shown)
--	CHARGE124.07A	Fuse Holder (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.