



Item	Part No.	Description
1	CP1812.01	Front Casing
2	CP1812.02	Front Casing Bush
3	CP1812.03	Front Casing Washer
4	CP1812.04	Front Impact Ass'y
5	CP1812.05	Rear Impact Ass'y
6	CP1812.06	Planetary Gear
7	CP1812.07	Planetary Gear Pin
8	CP1812.08	Bush (32 x 15.9mm)
9	CP1812.09	Washer for Gear Ring
10	CP1812.10	Gear Ring
11	CP1812.11	Gear Ring Cover
12A	CP1812.12A	Rotor (c/w Stator & Control Panel)

Item	Part No.	Description
14	CP1812.14	Rear Cover
15	CP1812.15	Screw ST4 x 23mm
16	CP1812.16	Screw ST5 x 40mm
17	CP1812.17	Casing Complete
18	CP1812.18	Screw ST4x14mm
19	CP1812.19	Switch
20	CP1812.20	Forward/Reverse Rod
22	CP1812.22	Battery Connector
23	CP1812.C	Main Charger 22V 2.2A
24	CP1812.24	Speed Adjustment Panel
25	CP1812.25	Belt Buckle
--	CP1812.BP	Battery Pack (not shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.