

INSTRUCTIONS FOR:

HEAVY DUTY WORKSHOP TROLLEY

fig. 1

Model No: CX208

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY, NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

- Always load evenly with the centre of gravity of the load as near the centre of the trolley as possible. 3
- Obtain additional support for large or wide loads to prevent tipping.
- Do not overload the trolley see Specification.
- Do not leave unattended, especially when loaded, unless the wheels are locked, chocked or the trolley otherwise secured.
- Do not use trolley on uneven ground and do not run over curbs or steps use a ramp.
- Do not allow others to ride on the trolley.
- Do not use the trolley if any part is significantly damaged, paying particular attention to the wheels.

SPECIFICATION & COMPONENTS

2.1. Specification

Max. Load Dimensions (L x W x H) 565 x 395 x 810mm

2.2. Components

1 - Tray (3) 4 - Castor, Unbraked (2) 7 - Washer (12) 10 - Screw (4) 2 - Frame (2) 5 - Angle Brace (12) 8 - Nut (12) 11 - Spring Washer (4) 12 - Wrench (1) 3 - Castor, Braked (2) 6 - Hex. Bolt (12) 9 - Ring Seat (4)

If any items are found to be damaged or missing contact your dealer immediately.

3. ASSEMBLY

Before assembly note that the trays can be fitted either way up, giving the choice of tray or shelf at each of the three levels.

3 1 Main assembly

- 3.1.1 Attach the three trays (A) to one of the frames (B) using the angle brackets, bolts, nuts and washers as shown in fig. 2.
- 3.1.2 Similarly attach the second frame (B) to the trays to complete the main assembly.

3.2 Wheels

3.2.1 Fit a castor to the bottom of each frame leg using ring seats, screws and washers as shown in fig. 3.

Fit both braked castors (C) to the same frame, as shown in fig. 1.





fig. 3



PARTS LIST

To be read in conjunction with figs. 1 and 2.

Item	Part No.	Description	Item	Part No.	Description	Item	Part No.	Description
1	CX208/01	Tray	5	CX208/05	Angle Brace	9	CX208/09	Ring Seat
2	CX208/02	Frame	6	CX208/06	Hex. Bolt	10	CX208/10	Screw
3	CX208/03	Castor, Braked	7	CX208/07	Washer	11	CX208/11	Spring Washer
4	CX208/04	Castor, Unbraked	8	CX208/08	Nut	12	CX208/12	Hex. Wrench (not shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



Sealey Group, PRODUCTS Bury St. Edmunds, Suffolk





01284 703534 E-mail: sales@sealey.co.uk