



Item	Part No.	Description
1	DG10073	Chimney Cap (S/Steel)
2	DG10074	Chimney (Black) 'for DG10 only'
	DG10081	Chimney (S/Steel) 'for DG11 only'
3	DG10075	Chimney Base (Black) 'for DG10 only'
	DG10082	Chimney Base (S/Steel) 'for DG11 only'
4	DG10579	Oven Body 'Black' (New Type) 'for DG10 only'
	DG10581	Oven Body 'S/Steel' (New Type) 'for DG11 only'
5	DG10077	Door (S/Steel)
--	DG10078	Temperature Gauge (not shown)
6	DG10084	Pizza Stone
7	DG10085	Wooden Handle

Item	Part No.	Description
8	DG10086	Fuel Feed Box
9	DG10580	Fuel Box 'Black' (New Type) 'for DG10 only'
	DG10582	Fuel Box 'S/Steel' (New Type) 'for DG11 only'
A	DG10088	Screw M5
B	DG10089	Screw M5
C	DG10090	Butterfly Screw M5 (4pcs/set)
D	DG10079	Smoking Cap (S/Steel) 'for DG10 only'
	DG10091	Smoking Cap 'for DG11 only'
--	DG39	Stainless Steel Pizza Paddle/Pizza Peel with Wooden Handle (not shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.