


Parts Information:

Hydraulic Drum Truck 205ltr Model No: DH01



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk



Parts Information:

Hydraulic Drum Truck 205ltr Model No: DH01

Item	Part No.	Description
1	DH01.01	Nut
2	DH01.02	Locking Washer
3	DH01.03	Wheel, Castor (W/Brake)(125x13x37x170)
4	DH01.04	Bottom Chassis
5	DH01.05	Pin
6	PT2200.336	External Circlip 22.5mm ID
7	DH01.07	E-Clip 14.7mm ID
8	DH01.08	Wheel, Front Fixed (D:200 W:50 B:40)
9	B/6204-2RS	Bearing 6204-2rs
10	DH01.10	Hexagon Socket Screw
11	DH01.11	Washer
12	DH01.12	Spring
13	SB-6.4	Steel ball 6.4mm
14	DH01.14	Connector
15	DH01.15	Fixed Board
16	DH01.16	Torsion Spring
17	DH01.17	Screw
18	DH01.18	Nut
19	DH01.19	Ring
20	DH01.20	Discharge Lever
21	DH01.21	O-Ring
22	DH01.22	Screw
23	DH01.23	Roller
24	DH01.24	Collar
25	DH01.25	Pin
26	SN10.S	Steel Nut M10 Zinc
27	DH01.27	Release Valve
28	DH01.28	Collar
29	DH01.29	Roller
30	DH01.30	Pin
31	DH01.31	Retaining Ring
32	DH01.32	Support Rack
33	DH01.33	Pin 12x64mm
34	DH01.34	Retaining Ring
35	DH01.35	Retaining Plate
36	DH01.36	Spring
37	DH01.37	Retaining Ring
38	DH01.38	Pin

Item	Part No.	Description
39	DH01.39	Ring
40	DH01.40	Collar
41	DH01.41	Knob
42	DH01.42	Clamp Tooth Operating ever
43	DH01.43	Plunger Lever
44	DH01.44	Dust-Proof Ring
45	DH01.45	O-Ring
46	DH01.46	Washer
47	DH01.47	Plunger Casing
48	DH01.48	Cylinder Tube
49	DH01.49	Sealing Board
50	DH01.50	Support Board
51	DH01.51	Plunger Casing
52	DH01.52	Pin
53	DH01.53	Split Pin
54	DH01.54	O-Ring
56	DH01.56	Bushing
57	DH01.57	Plunger Board
58	DH01.58	Plunger Casing
59	DH01.59	Washer
60	DH01.60	O-Ring
61	DH01.61	Dust-Proof Ring
62	DH01.62	Spring
63	DH01.63	Spring Cover
64	DH01.64	Rod
65	NLN10.S	Nyloc Nut M10 Zinc
66	DH01.66	Plunger Seat
67	DH01.67	Plunger Pin
68	DH01.68	Oil Cup
69	DH01.69	Bolt M10x68
70	SN8.S	Steel Nut M8 Zinc
71	DH01.71	Retaining Ring
72	DH01.72	Collar
73	DH01.73	Plunger Ring
74	DH01.74	Pin
75	DH01.75	Transporter Handle
	DH01.PUMP	Pump Assembly (parts 10-15, 21-22 & 43-74) (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk

