



Item	Part No.	Description
1	ECS350.01	Front Panel
2	ECS350.02	Cord Support
3	ECS350.03	Display Panel
4	ECS650.04	Handle
5	ECS350.05	Cable Reel Kit
6	ECS350.06	Clamp Support Kit
7	ECS350.07	Wheel Axle
8	ECS350.08	Wheel, Fixed (Set Of 2)
9	ECS350.09	Transformer
10	ECS650.10	PCB
11	SSTART500.15	Rectifier
12	ECS350.12	Fuse Support

Item	Part No.	Description
13	ECS350.13	Power Outlet M10 x 45mm
14	ECS350.14	Negative Cable
15	ECS350.15	Mains Cable
16	ECS650.16	Thermostat 13A
17	ECS650.17	Thermostat 11A
18	ECS350.18	Base
19	ECS650.20	Positive Clamp
19A	ECS650.20A	Negative Clamp
20	ECS350.20	Positive Cable
21	120/122351	Fuse
22	ECS350.22	Output Knob Kit
--	120/802260	Fuse, Pack of 20 (Not Shown)

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.