



ER1800PL/ER2000PL EXPLODED VIEW  
 (FROM 1-6-90)



**JACK SEALEY LIMITED**  
 Easlea Road, Moreton Hall Industrial Estate,  
 Bury St. Edmunds, IP32 7BY  
 Telephone: (0284) 769621 & 701261 (10 lines)  
 Telex 81476 · Fax: (0284) 703534

UNCONTROLLED DOCUMENT

ER1800PL/ER2000PL PARTS LIST

<u>FIG</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	42500510	Crown Pivot Block
2	35200510	O-ring
3	25200600	Spacer
4	25200570	Spring
5	25200520	Head
6	15209260	629Z Bearing
7	42500400	Bevel Gear
9	42500500	Spacer
10	23700522	Bearing Ring
11	15517400	6203-2RS Bearing
12	23700580	Drive Shaft
13	23700610	O-ring
14	25200530	Bottom cover
15	41609510	Rubber pad
16	41600810	21709540 Pad Nut <i>mit</i>
20	21500870	Side handle
23	15312320	6201ZZ Bearing
24	21081000	Fan
25	31126100	Felt Washer
26	23780500	Dust Seal
27	15710300	6200Z Bearing
28	23700740	Insulation Block
29	48200000	STator
30	66500990	Body Case complet
31	25200610	O-ring
32	35200550	Rubber Seat
33	21000810	Spring, Brush holder
34	21000960	Carbon Brush <i>14mm x 5.5mm x 22mm</i>
35	25253000	Brush holder
36	25200540	Cover, Brushes
37	21500790	Cable Clamp
38	25200550	Push Button
39	12004300	Pin
40	23700660	Spring
41	21000730	Condensor
42	21800821	Cable protection
43	23700700	Switch, Bi-power
44	80700000	Rotor
-	21700550	Pin spanner

ER2000PL

22	42600150	2-speed switch
45	80600000	Rotor
46	48300000	Stator



**JACK SEALEY LIMITED**

Easlea Road, Moreton Hall Industrial Estate,  
Bury St. Edmunds, IP32 7BY  
Telephone: (0284) 769621 & 701261 (10 lines)  
Telex 81476 · Fax: (0284) 703534