



Item	Part No.	Description
1	ES300/01	Main Beam
2	ES300/02	Beam Foot
3	ES300/03	Rubber Foot
4	ES300/04	Repair Washer M18
5	ES300/05	Top Clamp Assembly (c/w Grips)
6	ES300/06	Grip
7	ES300/07	Adjustable Screw

Item	Part No.	Description
8	ES300/08	Chain
9	SN16.S	Steel Nut M16
10	ES300/10	Beam Plug
11	ES300/11	Hand Wheel
--	ES300/02B	Foot Assembly (Not Shown)
--	ES300/04B	Washer (Not Shown)
--	ES300/11B	Knob (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.