



Item	Part No.	Description
1	HVF20S.01	Front Guard
2	HVF20S.02	Fan
3	HVF20S.03	Drum
4	HVF20S.04	Support Ring
5	HVF20S.05	Base / Base
6	HVF20S.06	Rear Guard
7	HVF20S.07	Motor

Item	Part No.	Description
8	HVF20S.08	Control Box
9	MC3CX0.75	Mains Cable
--	HVF20S.10	Switch, Rotary Power Selector (Not Shown)
--	HVF20S.10A	Selector Knob (Not Shown)
--	HVF20S.11	Capacitor (Not Shown)
--	HVF20S.12	Control Box Cover Plate (Not Shown)
--	HVF20S.FK	Fixing Kit, Wall Mounting (Not Shown)

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.