



Item	Part No.	Description
1	INV MIG200V201	HANDLE
2	IMIG180.02	COVER
3	INV MIG200V228	LATCH
4	INV MIG200V227	SPOOL HOLDER
5	IMIG180.05	SUPPORT POST (RED)
6	IMIG180.06	SUPPORT POST (BLACK)
7	INV MIG200V226	PANEL, LEFT SIDE (DOOR)
8	SMIG150.V3-38	WIRE FEEDER
9	IMIG180.09	MIDDLE PANEL
10	IMIG180.10	POTENTIOMETER
11	IMIG180.11	INDICATOR LIGHT
12	INV MIG200V223	POTENTIOMETER KNOB
13	SMIG130.27	MIG TORCH

Item	Part No.	Description
14	IMIG180.14	CONICAL NOZZLE
15	IMIG180.15	CONTACT TIP
16	IMIG180.16	EARTH CABLE & CLAMP
17	IMIG180.17	FRONT PANEL
18	IMIG180.18	CONTROL PCB BOARD
19	IMIG160.19-21	MAIN PCB BOARD
20	INV MIG200V213	BOTTOM PANEL
21	INV MIG200V208	FAN
22	IMIG180.23	BACK PANEL
23	IMIG180.24	GAS-VALVE CONNECTOR
24	IMIG180.24A	GAS-VALVE FITTING
25	INV MIG200V206	POWER SWITCH
26	IMIG180.26	POWER CORD

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.