


Parts Information: Vacuum Oil & Fluid Extractor Manual 4ltr Model No: MS156



Item	Part No.	Description
1	MS156.01	PUMP HANDLE
2	MS156.02	ТОР САР
3	MS156.03	PUMP TUBE (OUTER)
4	MS156.04	PUMP TUBE (INNER)
5	MS156.05	O-RING 31mm x 29mm x 3mm
6	MS156.06	SEAL RING (FLAT) 51mm x 37mm x 2mm
7	MS156.07	DAMPER
8	MS156.08	DAMPER PLATE
9	MS156.09	CIRCLIP

Item	Part No.	Description
10	MS156.10	TANK (4ltr)
11	MS156.11	SEAL RING (FLAT) 33mm x 20mm x 2.5mm
12	MS156.12	CAP (SMALL)
13	MS156.13	LID PLUG (SMALL)
14	MS156.14	COVER
15	MS156.15	FUNNEL
16	MS156.16	HOSE SHORT (10dia)
17	MS156.17	HOSE (8 dia)
18	MS156.18	HOSE (10 dia)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR 01284 757500 01284 703534 sales@sealey.co.uk

💮 www.sealey.co.uk