



| Item | Part No. | Description |
|------|-----------|--|
| 1 | MW200I-01 | Top Handle |
| 2 | MW200I-02 | Case |
| 3 | MW200I-03 | Main Control PCB |
| 4 | MW200I-04 | Front Panel Control Board |
| 5 | MW200I-05 | Front Plastic Panel |
| 6 | MW200I-06 | Negative Busbar |
| 7 | MW180I-07 | Front Panel Support Plate (For MW180I) |
| 7 | MW200I-07 | Front Panel Support Plate (For MW200I) |
| 8 | MW200I-08 | Potentiometer Knob |
| 9 | MW200I-09 | Cable & Electrode Holder |
| 10 | MW200I-10 | Cable & Earth Clamp |
| 11 | MW200I-11 | Quick Socket |

| Item | Part No. | Description |
|------|-----------|---------------------------------|
| 12 | MW200I-12 | Support Plate |
| 13 | MW200I-13 | Positive Busbar |
| 14 | MW200I-14 | Bottom Panel |
| 15 | MW200I-15 | Bottom Insulation Plate |
| 16 | MW200I-16 | Airflow Guide Plate |
| 17 | MW200I-17 | Support for Airflow Guide Plate |
| 18 | MW200I-18 | Fan |
| 19 | MW200I-19 | Fan Support |
| 20 | MW200I-20 | Rear Plastic Panel |
| 21 | MW200I-21 | Rocker Switch |
| 22 | MW200I-22 | Pwer Cable |

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.