



Item	Part No.	Description
1	PBI2212.01	PCB Assembly
2	PBI2212.02	Cable & Clamp, Negative (Black)
3	PBI2212.03	Cable & Clamp, Positive (Red)
5	PBI2212.05	Base, Bumper
6	PBI2212.06	Cover, Rear (Black)
7	RS21224.20	Battery
8	RS21224.12	Panel, Front
9	RS21224.21	Dc Adaptor Assembly
10	PBI1812S.14	Switch, Rotary Power
11	PBI2212.11	Knob, Rotary Switch
12	PBI2212.12	Cover, DC Socket

Item	Part No.	Description
13	RS21224.17	Tape, Narrow
14	RS21224.18	Tape, Medium
15	PBI4424S.46	Tape, Wide
--	PBI2212.04	Fuse (Not Shown)
--	PBI2212S.16	Label, Faceplate (Not Shown)
--	PBI2212S.L	Label, Product Number (Not Shown)
--	PBI2212S.L2	Label, Warning (Not Shown)
--	PBI2212S.L3	Label, DEKRA (Not Shown)
--	PBI.C	Charger (Not Shown)
--	PBI4424S.59	Fusible Link Cover, Plastic (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.