



Item	Part No.	Description
3	RS105.V2-03	Power Indicator
4	RS103.04	Case Assembly
5	RS105.05	Switch, Rotary Voltage
6	RS103.06	Socket, Cigarette Lighter (c/w Cap)
7	RS103.07	Clamp, Negative (c/w Cable)
8	RS103.08	Clamp, Positive (c/w Cable)

Item	Part No.	Description
9	RS10AUA	Universal Adaptor
10	RS103.10	Extension Cord
--	RS1/B	Battery (Not Shown)
--	RS105.02	LED Display Label (Not Shown)
--	RS103.04A	Case, Front (Not Shown)
--	RS103.04B	Case, Rear (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.