



Item	Part No.	Description
3	RS105.V3-03	Power Indicator
4	RS105.V3-04	Front Case (c/w Label)
5	RS105.05	Switch, Rotary
6	RS103.06	Cigarette Lighter Socket (c/w Cap)
7	RS103.07	Clamp, Negative (c/w Cable)
8	RS105.V3-08	Clamp, Positive (c/w Cable)
9	RS10AUA	Universal Adaptor
10	RS103.10	Extension Cord

Item	Part No.	Description
--	RS1/B	Battery (Not Shown)
--	RS105.V3-02	Led Display Label (Not Shown)
--	RS105.V3-04A	Back Case (c/w Label)(Not Shown)
--	RS103.11	Clamp Clips (Pair)(Not Shown)
--	RS105.L	Front Label (Not Shown)
--	RS105.L1	Back Label (Not Shown)
--	RS105.V3-11	Solenoid (Not Shown)
--	RS105.V3-L	Front Label (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.