



| ITEM | PART NO. | DESCRIPTION |
|------|-------------|---------------------------|
| 1 | C/246417666 | Cig. lighter socket w/cap |
| 2 | C/238555000 | Cable with clamp, black |
| 3 | C/312272000 | Holster, negative w/cap |
| 4 | C/248362666 | Extension cord, cig. plug |
| 5 | RS2/AX | AC charger (1500mA) |
| 6 | C/865886001 | PCB |
| 7 | C/312270000 | Red plastic button |
| 8 | C/312304000 | Case red, plastic, rear |
| 8a | C/312372000 | Case red, front |
| 9 | C/312271000 | Holster, positive w/cap |
| 10 | C/238554000 | Cable with clamp, red |
| 11 | C/246416666 | Circuit breaker |
| 12 | C/235007666 | Battery 12V - 17Ah |
| 13 | C/238558000 | Jumper cable assembly |

Issue: 1
 Issue Date: 06/02/06