



Item	Part No.	Description
1	SA91.V2-01	Housing
2	SA91.V2-02	Bushing
3	SA91.V2-03	Anvil Collar
4	SA401.03	O-Ring
5	SA91.V2-05	Anvil
6	SA91.V2-06	Pin
7	SA91.V2-07	Hammer Dog
8	SA91.V2-08	Drive Cam
9	SA91.V2-09	Hammer Cage
10	SA91.V2-10	Screw
11	SA91.V2-11	Trigger Pin
12	SA91.V2-12	Trigger
13	B/6900ZZ	Bearing
14	SA91.V2-14	Oil Seal
15	SA91.V2-15	Front Plate
16	SA91.V2-16	Rotor
17	SA91.V2-17	Rotor Blade
18	SA91.V2-18	Cylinder
19	SA91.V2-19	Pin
20	SA91.V2-20	End Plate
21	B/626ZZ	Bearing

Item	Part No.	Description
22	SA91.V2-22	Rear Gasket
23	SA91.V2-23	Rear Cover
24	SA91.V2-24	Air Inlet Block
25	SA91.V2-25	Air Regulator
26	GSA08.09-4	O-Ring
27	SA91.V2-27	O-Ring
28	SA91.V2-28	Spring
29	SA91.V2-29	Valve Stem
30	SA91.V2-30	Spring
31	SA91.V2-31	Valve Seat
32	SA91.V2-32	O-Ring
33	SA91.V2-33	O-Ring
34	SA91.V2-34A	Screw Assembly
36	SA91.V2-36	Fixing Ring
37	SA91.V2-37	E- Clip
38	SA91.V2-38	Spring
39	SB-3.0	Steel Ball
40	SA91.V2-40	Retainer Plate
41	SA91.V2-41	Screw
42	SA91.V2-42	Oil Seal
43	SA91.V2-43	Rubber

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.