



Item	Part No.	Description
1	SA92/01	Motor Housing
2	SA92/02	Valve Bushing
3	SA92/03	O-Ring
4	SA92/04	O-Ring
5	SA92/05	Valve Stem
6	SA92/06	Spring
7	SA92/07	Air Regulator
8	SA92/08	O-Ring
9	SA92/09	O-Ring
10	SA92/10	Valve Screw
11	SA92/11	Exhaust Sleeve
12	SA92/12	Nut
13	SA92/13	Adapter
14	SA92/14	O-Ring
15	SA92/15	Lever Pin
16	SA92/16	Bearing
17	SA92/17	Rear Plate
18	SA92/18	Pin
19	SA92/19	Cylinder
20	SA92/20	Rotor

Item	Part No.	Description
21	SA92/21	Rotor Blade
22	SA92/22	Bearing
23	SA92/23	Front Plate
25	SA92/25	Retainer
26	SA92/26	nUT
27	SA92/27	Guard
28	SA92/28	Tyre Buffing Wheel
29	SA92/29	Safety Lever
30	SA92/30	Spring Washer
31	SA92/31	Spacer
32	SA92/32	Arbor
33	SA92/33	Wrench
34	SA92/34	Wheel Assembly
35	SA92/35	Grinding Stone Set
36	SA92/36	3/8" Drill Chuck
37	SA92/37	Universal Joint
38	SA92/S	Connector
--	SA651/C	Tyre Buffing Cone & Arbor (Not Shown)
--	SA92/W01	Mounted grinding point 6mm (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.