


Parts Information:

Desk Fan 3-Speed 12" 230V Model No: SFF12



Item	Part No.	Description
1	SFF12.01	Front Cap
2	SFF12.02	Front Grille
3	SFF12.03	Fan Blade
4	SFF12.04	Screw
5	SFF12.05	Motor
6	SFF12.06	Screw
7	SFF12.07	Capacitor Cover
8	SFF12.08	Capacitor
9	SFF12.09	Switch, Rotary
10	SFF12.10	Rear Grille

Item	Part No.	Description
11	SFF12.11	Screw
12	SFF12.12	Knob
13	SFF12.13	Power Cord
14	SFF12.14	Screw
15	SFF12.15	Washer
16	SFF12.16	Side, Switch Cover
17	SFF12.17	Rubber Foot
18	SFF12.18	Base
19	SFF12.19	Screw
20	SFF12.20	Wire Clamp

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk