


Issue: 1  
 Date: 010802



Item	Part No	Description	Item	Part No	Description	Item	Part No	Description
1	126-48108000	Grip/handle	27	126-48102215	Pivot shaft lock nut	52	126-48108038	Oil tube
2	126-48108001	Inner protector	28	126-48108023	Bracket	54	126-48102234	Lever fixing screw
3	126-48102361	Switch	29	126-48108024	Spacer housing	55	126-48100200	Spring
4	126-48108002	Lever	30	126-48108025	Guide plate	56	126-48108039	Gasket
5	126-48108003	Bearing seal assembly	31	126-183000000	Armature	58	126-48108040	Blade drive shaft
6	126-48108004	Lever retaining nut	32	126-145900000	Field coil	59	126-48108041	Crown shaft worm bearing
7	126-48108005	Blade guard outer	33	126-48102224	Wire clamp screw	60	126-48108042	Bearing housing and seal
8		Bolt - UNI5739 M12x25	34	126-48108026	Wire clamp bracket	61	126-48108043	Pivot shaft
9	126-48108006	Clutch washer	35	126-48106501	Condensor	62	126-48108044	Return spring
10	126-48108007	Outer clutch cover	36	126-48108027	Motor body	63	126-48108045	Hook plate
11	126-48108008	Inner clutch cover	37	126-480004000	Cable sleeve	64	126-48005500	Spring washer
12	126-48102237	Circlip	38	126-48000204	Carbon brush	65	126-48108046	Spacer
13	126-48108009	Blade guard inner	39	126-48108028	Brush holder	66	126-48108047	Turning (pivot) bracket
14	126-48108010	Spacer	40	126-48108029	Brush cover	67	126-48108048	Degree scale plate
15	126-48108011	Vice assembly	41	126-48108030	Protective cover	68	126-48102335	Eccentric washer
16	126-48108012	Gasket	42	126-48108031	Spring	69	126-48108049	Base
17	126-48108013	O-ring	43	126-48108032	Handle	70	126-48108050	Pivot suport retainer
18	126-48108014	Bearing	44	126-48108033	Head (body)	71	126-48108051	Base tray
19	126-48108015	Washer	45	126-48108034	Toothed gear	72	126-48108052	Rubber foot cushion
20	126-48108016	End cover with oil level sight	46	126-48104907	Roller bearing	73	126-48108053	Push button
21	126-48108017	Worm drive shaft assembly	47	126-48104417	Spacer	74	126-48108054	Spring
22	126-48108018	Spring	48	126-50800950	Reduction gear	75	126-48108055	Hook
23	126-48108019	Sealing ring	49	126-48108036	Pump protective cover	76	126-48108056	Cover
24	126-48108020	Head gasket	50	126-40157500	Oil circulation pump	78	126-48004900	Filter (complete with oil pipes)
25	126-48108021	Front guard	51	126-48108037	Pump bracket	79	126-48006800	Filter
26	126-48108022	Outer protector						