



Item	Part No.	Description
1	SMS2004.01	Housing, Top
2	SMS2004.02	Base
3	SMS2004.03	Switch, Power Rocker
4	SMS2004.04	Motor
5	SMS2004.05	Pinion, Motor
6	SMS2004.06	Sharpening Wheel
7	SMS2004.07	Directional Label
8	SMS2004.08	Nut
9	MC2CX0.75	Mains Cable
10	SMS2004.10	Grip, Cable
11	SMS2004.11	Screw
12	SMS2004.12	PCB
13	SMS2004.13	Rubber Foot, Base
14	SMS2004.14	Base Screw
15	SMS2004.15	Fixing, Chuck
16	SMS2004.16	Support, Chuck
17	SMS2004.17	Locking Clamp
18	SMS2004.18	Gripping Clamp
19	SMS2004.19	Lock Nut
20	SMS2004.20	Counter Card

Item	Part No.	Description
21	SMS2004.21	Chuck, Right
22	SMS2004.22	Backing Sheet
23	SMS2004.23	Fixing Sheet
24	SMS2004.24	Screw
25	SMS2004.25	Fixing Shelf, Scissors
26	SMS2004.26	Plane, Blade Holder
27	SMS2004.27	Lock Nut
28	SMS2004.28	Angle Conditioner
29	SMS2004.29	Supporting Shelf
30	SMS2004.30	Move Instruction
31	SMS2004.31	Protective Guard
32	SMS2004.32	Card, Magnet
33	SMS2004.33	Magnet
34	SS320.S	Hex Head Set Screw M3 x 20mm
35	SMS2004.35	Tube, Fuse A
36	SMS2004.36	Fuse
37	SMS2004.37	Fuse Tube, B
38	SMS2004.38	Micro Switch
39	SMS2004.39	Bottom
40	SMS2004.40	Plastic Clip

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.