



| Item | Part No. | Description |
|------|---------------|------------------------------------------------------|
| 1 | SBOOST200V401 | Top Cover |
| 2 | SBOOST200V402 | Handle, Top Cover |
| 3 | SBOOST200V403 | Knob, Terminal, Od: 38mm, M8 Threaded Female Fitting |
| 4 | SBOOST200V404 | Positive Cable with Clamp |
| 5 | SBOOST200V405 | Back Cover (Plastic) |
| 6 | SBOOST200V406 | Cable Protector, Left |
| 7 | SBOOST200V407 | Cable Protector, Right |
| 8 | SN8.S | Steel Nut M8 Zinc |
| 9 | SBOOST200V409 | Negative Cable with Clamp |
| 10 | SBOOST160V510 | Power Cord |
| 11 | SBOOST160V411 | Thermostat |
| 12 | SBOOST200V412 | Bottom Panel |
| 13 | SBOOST160V413 | Transformer |
| 14 | SBOOST200V414 | Power Switch (Rocker) 30A 250V |
| 15 | SBOOST200V415 | Selector Switch, White Rocker 20A 250V |

| Item | Part No. | Description |
|------|---------------|---------------------------|
| 16 | SBOOST200V416 | Terminal Protection Cover |
| 17 | SBOOST200V417 | Fuse Cover |
| 18 | SN6.S | Steel Nut M6 Zinc |
| 19 | SBOOST160V519 | Fuse 50A 6.5x30 |
| 20 | SBOOST200V420 | Ammeter |
| 21 | SBOOST200V421 | Front Cover (Plastic) |
| 22 | SBOOST200V422 | Side Grip |
| 23 | SBOOST160V523 | Rectifier |
| 24 | SBOOST200V424 | Insulating Washer (B) |
| 25 | SBOOST200V425 | Insulating Washer (A) |
| 26 | SBOOST200V426 | Insulating Bolt |
| 27 | SBOOST200V427 | Insulating Plate |
| 28 | START800.17 | Terminal Bolt M8 |
| 29 | SBOOST200V429 | Shunt |
| 30 | SBOOST200V430 | Foot |

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.