




Parts Information:
**Wall Fan 3-Speed 18" with
 Remote Control 230V
 Model No: SWF18WR**



Item	Part No.	Description
1	SWF18WR.01	BRAND PLATE
2	SWF18WR.02	SCREW
3	SWF18WR.03	FRONT GRILL 18"
4	SWF18WR.04	SPINNER FOR BLADE
5	SWF18WR.05	BLADE 18"
6	SWF18WR.06	NUT FOR REAR GRILL
7	SWF18WR.07	REAR GRILL 18"
8	SWF18WR.08	FRONT MOTOR COVER
9	SWF18WR.09	SHAFT CLIP
10	SWF18WR.10	SCREW
11	SWF18WR.11	MOTOR
12	SWF18WR.12	SYNCHRONOUS MOTOR
13	SWF18WR.13	REAR MOTOR COVER

Item	Part No.	Description
14	SWF18WR.14	SCREW
15	SWF18WR.15	POWER CORD
16	SWF18WR.16	SCREW
17	SWF18WR.17	WALL BRACKET HOOK
18	SWF18WR.18	BASE COVER
19	SWF18WR.19	IC PANEL
20	SWF18WR.20	FRONT SWITCH BOX
21	SWF18WR.21	SCREW
22	SWF18WR.22	NUT
23	SWF18WR.23	SCREW
24	SWF18WR.24	BASE
25	SWF18WR.25	REMOTE CONTROLLER

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk