



MODEL N° TL80/TL81



TL80 TIMING LIGHT

TL80/01	Housing(Left)
TL80/02	Housing(Right)
TL80/03	P.C. Board
TL80/04	Name Plate
TL80/05	Name Plate
TL80/06	Front Ring
TL80/07	Push Button
TL80/08	2 Steps Switch
TL80/09	Socket
TL80/10	Lead and Plug
TL80/11	Screw
TL80/12	Back Cover Case
TL80/13	Name Plate (Back Side)
TL80/B2	Xenon Flash Tube

TL81 ADVANCE TIMING LIGHT

TL81/01	Housing(Left)
TL81/02	Housing(Right)
TL81/03	P.C. Board
TL81/04	Name Plate
TL81/05	Name Plate
TL81/06	Front Ring
TL81/07	Push Button
TL81/08	2 Steps Switch
TL81/09	Socket
TL81/10	Lead and Plug
TL81/11	Screw
TL81/12	Back Cover Case
TL81/13	Name Plate (Back Side)
TL81/14	V.R. (Variable Resistor)
TL81/15	Dial Plate
TL81/16	Rotary Switch (KNOB)
TL81/B2	Xenon Flash Tube