




Parts Information:  
**Air Operated Fuel Drainer 40L**  
**Model No: TP200**



**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.



Parts Information:  
**Air Operated Fuel Drainer 40L**  
**Model No: TP200**

Item	Part No.	Description
1	TP200.01	Hose 1/2" x 1m
2	TP200.02	Hose 3/8" x 1m
3	TP200.03	Hose 5/16" x 1m
4	TP200.04	Oil Filter
5	TP200.05	Extension Hose
6	TP200.06	Cap, Relief Valve
7	TP200.07	Tank Strap
8	TP200.08	Container
9	TP200.09	Wheel, Swivel Castor (c/w Brake)
10	TP200.10	Tank Lid
11	TP200.11	Air Intake Assembly
12	TP200.12	Air Regulator Assembly
12-1	TP200.12-1	Gauge
12-2	TP200.12-2	Cover, Gauge
13	TP200.13	Pump
14	TP200.14	Hose Assembly (c/w Hose Connectors)
15	TP200.15	Wheel, Fixed (c/w Bearing)
16-1	TP200.16-1	Adaptor H19 x M10 x 41.5L
16-2	TP200.16-2	Adaptor H19 x M14 x 41.5L
16-3	TP200.16-3	Adaptor H19 x M12 x 41.5L
16-4	TP200.16-4	Adaptor H19 x 6.5mm x 40.5L
16-5	TP200.16-5	Adaptor H19 x 8.5mm x 40.2L
16-6	TP200.16-6	Adaptor H19 x 10.5mm x 40.2L
17	TP200.17	Earth Cable, Green
18	TP200.18	Earth Cable, Yellow
19	TP200.19	Hose
20	TP200.20	Hose 10mm x 16mm x 550mm
21	TP200.21	Hose 4mm x 8mm x 1000mm
22	TP200.22	Wire Hose
23	TP200.23	PU Hose
24	TP200.24	Seat, Air Filter
25	TP200.25	Level Tube

Item	Part No.	Description
26	TP200.26	Elbow
27	TP200.27	Pad, Adaptor Seat
28	TP200.28	Adaptor Seat
29	TP200.29	Adaptor, Main Hose
--	TP200.11-1	Air Intake Bracket Kit (Not Shown)
--	TP200.11-2	Body, Air Intake (Not Shown)
--	TP200.11-3	Hose Connector (Not Shown)
--	TP200.11-4	Shaft, Knob (Not Shown)
--	TP200.12-3	Regulator Ring (Not Shown)
--	TP200.12-4	Hose Connector, Air Regulator (Not Shown)
--	TP200.12-5	Connecting Block (Not Shown)
--	TP200.12-6	Regulator Body (Not Shown)
--	TP200.12-7	Valve, Air Regulator (Not Shown)
--	TP200.13A	Pump Bracket (Not Shown)
--	TP200.19-1	Adaptor, Main Hose (F)(Not Shown)
--	TP200.19-2	Main Hose Connector A (Not Shown)
--	TP200.19-3	Main Hose Connector B (Not Shown)
--	TP200.30	Overflow Valve (Not Shown)
--	TP200.31	Elbow (Not Shown)
--	TP200.32	Knob, Red (Not Shown)
--	TP200.33	Knob, Green (Not Shown)
--	TP200.34	Frame Assembly (Not Shown)
--	TP200.35	Elbow, Tank (Not Shown)
--	TP200.36	Plastic Tube (Not Shown)
--	TP200.37	Screw (Not Shown)
--	TP200.38	Hose Clip (Not Shown)
--	TP200.39	Clamp, Plastic Tube (Not Shown)
--	TP200.40	Bolt, Top Frame (Not Shown)
--	TP200.41	End Cap, Handle (Not Shown)
--	TP200.42	Bracket (Not Shown)
--	TP200S.24	Air Filter Seat (Not Shown)
--	TP200V3-05A	Tank Lid (c/w Nut)(Not Shown)

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.

**Sealey Group**, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk