



Item	Part No.	Description
1	VS230.01	Bottom Panel
2	VS230.02	Front Panel
3	VS230.03	Socket For Control (Large)
4	VS230.04	Socket For Control (Small)
5	VS230.05	Led (Green)
6	VS230.06	Led (Red)
7	VS230.07	Fan
9	VS230.09	Aux Transformer
10	VS230.10	Radiator
11	VS230.11A	PCB, Main Control Board, 290 X 94mm
11	VS230.11B	PCB, Charging Board, 74 X 72mm
12	VS230.12	Switch (On/Off) Red Rocker 25a 250v
13	VS230.13	Power Cable 2.5 Metre
16	VS230.V2-16	Top Case

Item	Part No.	Description
17	VS230.17	Handle
18	VS230.18	Plastic Foot
19	VS230.19	Heating Forch
20	VS2306	Induction Coil - Side Ø30mm
21	VS2304	Induction Coil - Side Ø20mm
22	VS2305	Induction Coil - Direct Ø30mm
23	VS2303	Induction Coil - Direct Ø20mm
24	VS2309	Induction Coil - Pad Ø55mm
25	VS230.25	Power Selection Rocker Switch (High/Low) 6a
26	VS230.26	Power Plug 3 Pin
27	VS2311	Induction Block
28	VS2310	Induction Coil - Flex 920mm
--	VS230.19A	Knob, Plastic, Knurled, OD: 17mm, M4x12mm Threaded Male Fitting (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.