

INTUMESCENT STRIP RECESSING CUTTER REF. 345

Thank you for purchasing this Trend router cutter, which should give lasting performance if used in accordance with these instructions.

The following symbols are used throughout these instructions.



Denotes risk of personal injury, loss of life or damage to the tool in case of non-observance of the instructions

Refer to the instruction manual of your power tool.

This cutter must not be put into service until it has been established that the power tool to be connected to this unit is in compliance with 2006/42/EC (identified by the CE marking on the power tool).

INTENDED USE

This cutter is intended to be used in a router to produce the correct width and depth of cut for standard 20mm x 4mm intumescent strip in a fire door and frame

INST/345 v3 1



SAFETY

Please read and understand the safety points at the end of this instruction as well as the power tool instructions before use.

PLEASE KEEP THESE INSTRUCTIONS IN A SAFE PLACE.

The attention of UK users is drawn to The Provision and Use of Work Equipment Regulations 1998, and any subsequent amendments

Users should also read the HSE/HSC Safe Use of Woodworking Machinery Approved Code of Practice and Guidance Document and any amendments.

Users must be competent in using woodworking equipment before using our products. Please keep children and visitors away from tools and work area. All tools have a residual risk, so must therefore be handled with caution.


ITEMS REQUIRED

- Router with suitable collet fitted.
- 13mm A/F spanner.
- Intumescent strip.
- Hand tools.
- Trestle x2.
- Clamps x2.

Ensure working position is comfortable and component is clamped securely. Consider working environment before using tools.

ITEMS ENCLOSED & DESCRIPTION OF PARTS

- A. Arbor **x1**
- B. Bearing 32mm diameter x1
- C. Slotter 20mm kerf x 40mm dia. x1
- D. Instructions x1



OPERATION


Carefully remove the protective wax from the cutter and dispose

Insert the cutter shank into the collet at least all the way to the marked line indicated on the shank. This ensures at least 3/4 of the shank is held in the collet.

The cutter can be used freehand in any portable router which has the capacity to take a 1/2" (12.7mm) shank. If the cutter is to be used in a workshop environment then the cutter can be used in routers which are mounted in an overhead mode or are inverted in a table. To use the router in a stationary position would necessitate machining any stiles or rails before the final assembly of the door or frame.

The cutter should be used at the full speed of the router.





Diagrams show the technique for machining a wider groove to accept wider strip.

Before using cutter, please ensure it is

correctly assembled and locking nut/

aroover is fully tightened to correct torque

/!\

settina.

ENVIRONMENTAL PROTECTION Recycle raw materials instead of disposing as waste.

Packaging should be sorted for environmentalfriendly recycling.

The product and its accessories at the end of its life should be sorted for environmentalfriendly recycling.

GUARANTEE

All Trend products are guaranteed against any defects in either workmanship or material, except products that have been damaged due to improper use or maintenance.

© Trend Machinery & Cutting Tools Ltd. 2014 E&OE ® All trademarks acknowledged


Trend Machinery & Cutting Tools Ltd.

Odhams Trading Estate St Albans Road Watford WD24 7TR England Tel: 0044(0)1923 249911 technical@trendm.co.uk www.trend-uk.com



Types of Intumescent Strip

Intumescent Strip




Intumescent Strip

with Smokeseal

Types of Applications /!\

For either frame or door applications, with standard or smokeseal Intumescent Strip.

Door Applications Half hour rating One hour rating



Frame Applications Half hour rating One hour rating



/!\

The material being cut will need to be supported and held securely.

ACCESSORIES

Please use only Trend original accessories.

Alternative Bearings

Adding alternative A spacer set Het. SPACER/12 may be 3mm-required for some bearings

Strip Thickness	Bearing Ømm	Ref. (1 off)
7	26	B26
6	28	B28
5	30	B30
3	34	B34
2	36	B36

SPARE PARTS

Please use only Trend original spare parts and accessories

Item	Qty.	Desc.	Ref. (1 off)
Α	1	Arbor 1/2" shank	33/20X1/2
В	1	Bearing 32mm dia.	B32
С	1	Slotter 20mm kerf	34/17TC
D	1	Instructions	INST/345

MAINTENANCE Z

Please use only Trend original spare parts and accessories.

Continual satisfactory operation depends upon proper tool care and regular cleaning.

Cleaning

-B32

20mm

- B26

- B28

-B30

B34

_B36

- Ensure clamping surfaces are cleaned to remove dirt, grease, oil and water.
- Remove resin build-up regularly.
- Apply a rust protector to shanks. Do not use rust protector on ball bearing guides.

Lubrication

Use a PTFE dry lubricant spray on tool to increase cutting edge life.

Storage

Always return cutter to its packaging after use.

Safety Points

- Disconnect power tool and attachment from power supply when not in use, before servicing, when making adjustments and when changing accessories such as cutters. Ensure switch is in "off" position and cutter has stopped rotating.
- 2. Read and understand instructions supplied with power tool, attachment and cutter
- 3. Current Personal Protective Equipment (PPE) for eve, ear and respiratory protection must be worn. Keep hands, hair and clothes clear of the cutter.
- . Before each use check cutter is sharp and free from damage. Do not use if cutter is dull, broken or cracked or if any damage is noticeable or suspected.
- 5. The maximum speed (nmax) marked on tool or in instructions or on packaging shall not be exceeded. Where stated, the speed range should be adhered to.
- Insert the shank into the router collet at least all the way to the marked line indicated on the shank. This ensures at least 3/4 of shank length is held in collet. Ensure clamping surfaces are clean.
- Check all fixing and fastening nuts, bolts and screws on power tool, attachment and cutting tools are correctly assembled, tight and to correct torque setting before use.
- 8. Ensure all visors, guards and dust extraction is fitted.
- 9. The direction of routing must always be opposite to the cutter's direction of rotation.
- 10. Do not switch power tool on with the cutter touching the workpiece.
- 11. Trial cuts should be made in waste material before starting any project.
- 12. Repair of tools is only allowed according to tool manufacturers instructions
- 13. Do not take deep cuts in one pass, take shallow passes to reduce the side load applied to the cutter.
- Please see www.trend-uk.com/safety for more safety advice.



Our policy of continuous improvements mean that specifications may change without notice. Trend Machinery & Cutting Tools Ltd. cannot be held liable for any material rendered unusable, or for any form of consequential loss.

bearings will give a	ve to
different depth of cut	Depth of groove most popular in
allowing you to use	oth of
the cutter for other	De
sizes of intumescent	4mi
strip and other	
applications that may	
arise. This diagram	
shows the different	7mm
depths that can be	
achieved by using	6mm 🕳
alternate bearings.	5mm -
A spacer set Ref	0