




THP2 Filter

**AIR/1** - (3 pack)

**AIR/10** - (1 pack)

Pre-filter **AIR/2**



INST/AIR/1 v7.1

**trend**<sup>®</sup>  
routing technology

Please  
read carefully  
before use

## FILTER

### REF. AIR/1, AIR/10 & AIR/2

Thank you for purchasing this Trend product which should give lasting performance if used in accordance with these instructions.

The following symbols are used throughout these instructions.



Denotes risk of personal injury, loss of life or damage to the tool in case of non-observance of the instructions.

## INTENDED USE

This accessory is intended to be used with the Trend Airshield Powered Respirator.

## SAFETY

Please read and understand the safety points at the end of this instruction as well as the power tool instructions before use.

PLEASE KEEP THESE INSTRUCTIONS IN A SAFE PLACE.

Users must be competent in using woodworking equipment before using our products.

Ensure working position is comfortable. Please keep children and visitors away from tools and work area. All tools have a residual risk, so must therefore be handled with caution.

## FITTING INSTRUCTIONS

### REF. AIR/1 & AIR/10 - THP2 FILTER

Release the cover by lifting the left and right lower sides to disengage the lugs then pull forward and lift.




Precautions are to be taken to prevent inhalation of harmful dust or contaminant retained on the main filter and inside the cover.

Pull the corners of the main filter to release the four press studs from the housing.

Dispose of in accordance with local health and safety regulations. Never re-use a main filter.

Wipe down with a damp cloth to remove any loose dust from inside the cover and housing.

Fit a new main filter by attaching the two press studs onto the housing. Support the housing and press along the main filter edges, attach the other end onto the two press studs. Ensure the filter seal is fully seated on the housing. Lower the cover and push backwards to engage the lugs into the holes. Ensure the lugs are fully engaged in the holes. Carry out a functional test as described in the Airshield manual.



© Trend Machinery & Cutting Tools Ltd. 2014 E&OE  
© All trademarks acknowledged

**GB** **Trend Machinery & Cutting Tools Ltd.**  
Tel: 0044(0)1923 249911  
technical@trendm.co.uk  
www.trend-uk.com

**USA** **Trend Routing Technology Inc.**  
Tel: 336 292 5051  
technical@trend-usa.com  
www.trend-usa.com



RECYCLABLE

## **FITTING INSTRUCTIONS**

### **REF. AIR/2 - PRE-FILTER**

Release the cover by lifting the left and right lower sides to disengage the lugs then pull forward and lift.



**Precautions are to be taken to prevent inhalation of harmful dust or contaminant retained on the pre-filter and inside the cover.**

Pull pre-filter away from inside the cover and dispose of in accordance with local health and safety regulations. Never re-use a pre-filter.

Wipe down with a damp cloth to remove any loose dust from inside the cover.

Attach the coarse side of the replacement pre-filter onto the hook fastener strips inside the cover. Lower the cover and push backwards to engage the lugs into the holes. Ensure the lugs are fully engaged in the holes. Carry out a functional test as described in the Airshield manual.

## **ENVIRONMENTAL PROTECTION**

### **Recycle raw materials instead of disposing as waste.**

Packaging should be sorted for environmental-friendly recycling.  
The product and its accessories at the end of its life should be sorted for environmental-friendly recycling.

## **GUARANTEE**

All Trend products are guaranteed against any defects in either workmanship or material, except products that have been damaged due to improper use or maintenance.