



# Chair



SPLATS	11
SIDERAIL_2	10
SIDERAIL_1	9
RIGHT_LEG	8
REARLEG_RIGHT	7
REARLEG_LEFT	6
LEFT_LEG	5
FRONT_RAIL	4
CROWN_RAIL	3
BRACE	2
BACK_RAIL	1

**trend**  
routing technology

® Technical Support:  
0044(0)1923 224681  
technical@trendm.co.uk  
www.trendmachinery.co.uk  
© Copyright Trend 2003.